


INSTRUCTION MANUAL

PNEUMATIC BELT SANDER

Please read this manual carefully before you attempt to use your tool so that you may use it properly and safely.

BELTON Model B-10CL, B-20CL, B-20CL-A, B-30CL PROFESSIONAL TOOL



Specifications

Model	B-10CL	B-20CL	B-20CL-A	B-30CL
Maximum Operating Pressure MPa		0.6		
Air Consumption (No Load) m ³ /min	0.4	0.48	0.48	0.82
Rated Speed (No Load) min ⁻¹	17000	18000	18000	15000
Standard Belt Size mm	10x330 (25/64"x13")	20x520 (25/32"x20-15/32")		30x540 (1-3/16"x21-17/64")
Mass (Weight) kg	0.9	1.6	1.5	2.4
Sound Pressure Level [Uncertainty K] dB(A)	78 [≤ 2.0]	81 [≤ 2.0]	80 [≤ 2.0]	86 [≤ 2.0]
Sound Power Level [Uncertainty K] dB(A)	89 [≤ 2.0]	92 [≤ 2.0]	91 [≤ 2.0]	97 [≤ 2.0]
Vibration Level [Uncertainty K] m/s ²	≤ 2.5 (1.2 [0.75])	≤ 2.5 (1.32 [0.19])	≤ 2.5 (1.09 [0.37])	Grip: ≤ 2.5 (0.56 [0.17]) Sub handle: ≤ 2.5 (1.88 [0.3])
Thread Size of Air Inlet	Rc 1/4			

The specifications and configurations contained in this document are subject to change without prior notice due to improvements we are making day in, day out.

Manufactured by :



NITTO KOHKI Co., Ltd.
9-4, NAKAIEGAMI
2-CHOME, OHTA-KU,
TOKYO, 146-8555, JAPAN
Tel : +81-3-3755-1111
Fax : +81-3-3753-8791

Keep the manual handy – so you can use it whenever necessary.

Original Instructions

Thank you very much for your purchase of this **Nitto Kohki product**.

Before using your tool, please read this manual carefully so that you may use it properly to get the most out of it.

Please keep the manual handy - so you can use it whenever necessary.

- **English** : Please ask your dealer or distributor for instruction manual in local language(s).
- **German** : Bitte fragen Sie Ihren Händler nach eine Betriebsanleitung in Landessprache.
- **French** : S'il vous plait, veuillez demandez à votre fournisseur de manuel instruction en langue locale.
- **Spanish** : Por favor, contacte con su distribuidor para el manual de instrucciones en español.
- **Portuguese** : Por favor pessa ao seu agente ou distribuidor o manual de instruções em linguagem local.
- **Italian** : Per Manuale Istruzioni in lingua locale Vi preghiamo di rivolgervi al rivenditore o distributore.
- **Dutch** : Vraag uw handelaar om een nederlands talige gebruiksaanwijzing.
- **Swedish** : Be er lokala Åtreförsäljare eller distributör om manualer på svenska.
- **Danish** : Venligst henvend Dem til den danske distributør for instructions manualer.
- **Polish** : Prosze pyta swojego dealera lub dystrybutora o instrukcje obsługi w języku localnym.
- **中文** : 請向當地供應商或經銷商詢問中文使用說明書

CONTENTS

	page
IMPORTANT SAFETY INSTRUCTIONS	2
GENERAL: TOOLS	2
GENERAL: PNEUMATIC TOOLS	3
INSTRUCTIONS FOR THIS TOOL	4
1. USAGE	4
2. CHECK THE CONTENTS OF THE PACKAGE	4
3. NAME OF PARTS	5
4. AIR SUPPLY	5
5. PREPARATION	6
6. HOW TO OPERATE THE TOOL	7
7. THREAD SIZE OF HOSE FITTING	9
8. STORAGE AND MAINTENANCE	10
9. ORDERING SERVICE PARTS	10
10. OPTIONAL PARTS	10

PICTOGRAM

-  **Warning:** It might be dangerous to operate the tool if the instructions supplied are not followed.
-  Using this tool improperly could result in serious injury. Read the instruction manual before using.
-  Always wear suitable eye protection.
-  Always wear suitable hearing protection.
-  Always wear respiratory protective equipment (PPE).
-  Always wear protective gloves for protection of hands from Vibration and Shock

The following Safety notations are used throughout the manual to highlight safety precautions for the user and for the tool.

 Warning:	Indicates a potentially hazardous situation which, if not avoided by following the instructions given, could result in death or serious injury.
 Caution:	Indicates a potentially hazardous situation which, if not avoided by following the instructions given, could result in injury or material damage.

Please note, however, that failure to observe safety precautions under the “**Caution**” category could result in a serious occurrence depending on the situation: please observe all safety precautions in the manual.

Caution: Important precautions for tool setup, operation and maintenance.

IMPORTANT SAFETY INSTRUCTIONS

When using the tool, please observe the safety precautions below to prevent possible accident or injury.

⚠ Warning

Some dust created by power sanding, sawing, grinding, drilling, and other construction activities contains chemicals known [to the State of California] to cause cancer birth defects or other reproductive harm. Some examples of these chemicals are:

- lead from lead-based paints,
- crystalline silica from bricks and cement and other masonry products, and
- arsenic and chromium from chemically-treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals : work in a well ventilated area, and work with approved safety equipment, such as those dust masks that are specially designed to filter out microscopic particles.

GENERAL: TOOLS

⚠ Warning

TO OPERATORS

• Wear proper clothing for the type of work being done.

Take care to avoid entanglement with the moving parts of the tool with clothing, ties, hair etc. If items become entangled it will cause the operator to be pulled towards the tool and lead to possible cause of accident or injury.

• Always wear suitable eye protection.

Vision correction glasses are not safety glasses.

Always wear appropriate safety glasses when doing your job.

• Always wear suitable hearing protection.

• Wear respiratory protective equipment (PPE).

Wear respiratory protective equipment (PPE) when working in an environment where dust particles are generated in operation.

• Avoid working posture that is too stressful.

Always ensure a firm footing and well balanced posture.

• Do not operate the tool if you are too tired.

• Never touch any moving parts of the tool when running.

ABOUT WORK AREA

• Keep the work area clean.

Cluttered work areas (e.g. workbench) invite accidents.

• Carefully select the work area.

Do not expose tool to rain.

Do not use tool in a wet or soaked area.

See that the work area is adequately illuminated.

• Never work near inflammable liquid or in a potentially explosive atmosphere.

• Keep children away from the work area.

Keep children and unauthorized people away from the work area to avoid accident or injury.

• Some tools generate high noise levels.

Check to be sure that the use of this tool conforms to all local noise regulations.

BEFORE OPERATION

• Inspect tool before use.

Before using, check that screws are securely tightened, that any protective cover or guard is securely in place, other parts are free from damage and that the tool runs as it should.

Check that moving parts are properly adjusted for positioning and tightened, that parts are free from damage and properly mounted, and that all other parts are in good condition for normal operation.

Should you find any damage to the protective cover or other part, replace it in accordance with the Operation Manual. If there are no instructions in the Manual, please contact the sales agent through which you have purchased your tool or an authorized dealer near you for repair.

Likewise, if a switch failure occurs, contact sales agent through which you have purchased your tool or an authorized dealer near you for repair.

Do not use the tool if it does not start or stop with the start/stop switch.

• Securely mount cutter

An improperly mounted cutter may fly out, causing possible damage to the tool or injury to the operator.

• Always remove spanner, wrench, etc., once adjustment has been made with them.

• Use a tool appropriate for the application.

Avoid heavy-duty application that is beyond the capacity of tool.

• Do not use the tool for purposes other than what it is designed for.

• Do not abuse tool.

Use tool in accordance with the specifications: you'll get the most out of it while ensuring safety.

• Securely fasten workpiece in place.

Use a vice or clamp to securely fasten the workpiece

in place. It is much safer this way than holding it in your hand, allowing you to operate the tool with both hands.

ABOUT HANDLING

- **How to store tool.**

When the tool is not used, store it in a dry area and out of reach of children.

- **How to carry tool.**

Do not touch the start switch while the tool is being carried.

- **Do not leave the tool unattended while it is running.**

Turn off the start switch and disconnect the tool from power source. Do not leave the work area until the tool comes to a complete stop.

MAINTENANCE/SERVICE

- **Do not take apart or modify tool.**

Disassembly or modification carried out without the supervision of a qualified or authorized service engineer could result in an accident or injury.

- **Inspect cutting tool and accessories, etc.**

Always check to see that cutting tool and accessories, etc. are in good operating condition without damage or deterioration before you mount them on the tool. Should you find any damage to an accessory or part, please contact sales agent through which you have purchased your tool or an authorized dealer near you for repair.

- **Check parts for damage.**

When you have found damage to accessory or other part, carefully check the damaged part to determine the extent of influence it has upon the functions of the tool – that is, determine whether it can still perform its normal functions.

Check to see that the linkage of the moving parts is OK, that all parts are OK without damage, that they are properly mounted, and that the tool functions normally. Should you find any damage to an accessory or part that may hamper proper functioning of the tool, please contact sales agent through which you have purchased your tool or an authorized dealer near you for repair.

- **Have your tool repaired at an authorized Nitto Service Center.**

For repair or parts replacement, please contact the sales agent through which you have purchased your tool or an authorized dealer near you.

- **Use only Nitto genuine parts.**

Use of improper parts may result in serious occurrence.

To obtain a Nitto genuine part, consult this Manual

or contact the sales agent from which you have purchased your tool directly.

- **Do not detach label or nameplate from tool.**

When a label/nameplate gets damaged, worn or becomes missing, contact the sales agent through which you have purchased your tool or Nitto Kohki Co. Ltd, directly for a replacement.

DISPOSAL

When a tool is taken permanently out of service, it is advised that the tool is disassembled, degreased and parts separated by material and recycled locally in the appropriate manner.

GENERAL: PNEUMATIC TOOLS

⚠ Warning

- **Use appropriate air pressure.**

Excessively high air pressure will increase the number of revolutions or strokes causing not only potential premature failure/breakage but could also lead to an unexpected accident or injury.

- **Connect tool to air supply line.**

There are various types of pipes running in a factory in addition to the pneumatic line (such as oxygen, nitrogen, gas and water). For this reason, always ensure that you are connecting to the pneumatic line.

- **Start tool properly.**

Turn the start switch OFF before connecting to the air supply line.

- **Always disconnect the tool from the air supply line before putting on/taking off any accessory and prior to carrying out any maintenance work.**

- **Avoid exposure to exhaust air.**

Pneumatic tool exhaust air contains oil and contaminated moisture. Make sure the exhaust air is not directed towards your face or anyone else within the work area.

- **Keep tool off electricity.**

This pneumatic tool is not electrically insulated. To avoid a potential electric shock do not use where there is a possibility of coming into contact with live electricity.

⚠ Caution

- **Handle tool carefully.**

Abusive use of tool could invite failure or accident.

Do not throw, drop or shock the tool.

- **Handle air hose carefully.**

Do not carry the tool by the air hose.

Do not pull the air hose to disconnect.

INSTRUCTIONS FOR THIS TOOL

About Your Tool

⚠ Warning

- **Wear protective glasses and a dustproof mask.**
Operation generates dust and abrasive particles, etc. which may cause eye and/or respiratory injury: Always use PPE (Personal Protective Equipment) for eye and respiratory protection.
- **When you change or adjust the tool or parts, be sure to detach the tool from the air hose.**
- **Never touch the moving parts while in operation.**

⚠ Caution

- **Protect yourself from dust and abrasive particles.**
When sanding hot dust and abrasive particles fly off the workpiece: Always wear eye protection glasses, long sleeve protective clothing, gloves (except knitted gloves), foot and leg protection, etc. to protect yourself. Always keep your face away from the sanding surface.


1. USAGE

This is a handheld pneumatic belt sander designed and built to perform sanding operation utilizing a abrasive belt.

2. CHECK THE CONTENTS OF THE PACKAGE

Check the contents and make sure that the tool does not have any damage which may have occurred during transportation. The contents should correspond to the list as follows. In case of damage/missing parts, please contact the sales agent from whom you purchased the tool.


Model	Package Contents	Qty	Check
B-10CL	B-10CL	1set	
	Abrasive Belt Z76#60x10	2(one of them mounted)	
	Abrasive Belt Z76#80x10	1	
	Abrasive Belt Z76#100x10	1	
	Abrasive Belt Z76#120x10	1	
	Hex. Socket Screw Key 1.5	1	
	Hex. Socket Screw Key 4	1	
	Bushing R1/4xNPT1/4	1	
	Instruction Manual	1	
	Declaration of Conformity	1	
	Caution for Use	1	




Tool Body



Abrasive Belt




Hex. Socket Screw




Bushing R1/4xNPT1/4

Model	Package Contents	Qty	Check
B-20CL / B-20CL-A	B-20CL / B-20CL-A	1set	
	Abrasive Belt Z76#60x20	2(one of them mounted)	
	Abrasive Belt Z76#80x20	1	
	Abrasive Belt Z76#100x20	1	
	Abrasive Belt Z76#120x20	1	
	Hex. Socket Screw Key 2.5	1	
	Hex. Socket Screw Key 4	1	
	Bushing R1/4xNPT1/4	1	
	Convex Shoe	1	
	Silencer Sub Ass'y	1set	
	Instruction Manual	1	
	Declaration of Conformity	1	
	Caution for Use	1	




Tool Body




Abrasive Belt



Hex. Socket Screw



Bushing R1/4xNPT1/4




Convex Shoe




Silencer Sub Ass'y


Model	Package Contents	Qty	Check
B-30CL	B-30CL	1set	
	Abrasive Belt Z76#60x20	2(one of them mounted)	
	Abrasive Belt Z76#80x20	1	
	Abrasive Belt Z76#100x20	1	
	Hex. Socket Screw Key 5	1	
	Bushing R1/4xNPT1/4	1	
	Silencer Sub Ass'y	1set	
	Handl Ass'y	1set	
	Instruction Manual	1	
	Declaration of Conformity	1	
	Caution for Use	1	




Tool Body



Abrasive Belt




Hex. Socket Screw



Bushing R1/4xNPT1/4



Silencer Sub Ass'y



Handl Ass'y



3. NAME OF PARTS




Fig.1

4. AIR SUPPLY

⚠ Caution

- **Draw off drainage before starting operation. If the drainage enters into the tool, it can freeze around the exhaust port of the tool and result in output power reduction.**

4-1. Air Pressure

Adjust air pressure to 0.6MPa (or 6 kgf/cm²) with the air regulator. Lower pressure may result in insufficient performance. Higher pressure may result in premature wornout of parts. It is important to maintain the proper pressure with pressure regulator on air line.

4-2. Air Line (Fig.2)

Use a 9.5 mm (3/8") I.D. air hose between the compressor and the tool. Compressed air comes

to be cooled down and its drain be separated, as soon as the air leaves the compressor. The drain, however, is condensed in the piping, and can enter into the tool mechanism, and may cause malfunction. So, install an air filter and an oiler between the compressor and the tool.

4-3. Oiler

Install an oiler between the compressor and the tool. Use machine oil ISO VG-10 for lubrication and rust prevention. Negligence of the oil supply may cause damages on the tool. Lubricating the tool with high viscosity oil reduces the tool performance.

4-4. Lubrication (Fig.2)

Before starting the tool, disconnect air hose from the tool and supply a few drops of machine oil ISO VG-10 to the air inlet port of the tool. Then reconnect

and make idle running for a few seconds so that the oil should reach every part in the tool.




Fig. 2

5. PREPARATION

5-1. Fastening the Guard

⚠ Caution

- **No clearance should be allowed between the Housing and the Guard. Any clearance, if there is between them, can cause the Abrasive Belt to come off, resulting in injury to the operator or damage to the equipment or both.**

You can set the Guard at any angle you may find best suited for your working posture or the configuration of workpiece. Once you have placed the Guard at a desired angle, tighten the Hex. Socket Head Cap Screw per "A" in Fig. 4 with a Hex. Socket Screw Key. At that time, carefully fasten the Guard so that there is no clearance between the Housing and the Guard.






Fig.3

Carefully fasten the Guard so that there is no clearance between the Housing and the Guard.



B-10CL



B-20CL, B-20CL-A

Carefully fasten the Guard so that there is no clearance between the Housing and the Guard.




Fig.4

5-2. How To Fix Silencer (B-20CL, B-20CL-A, B-30CL) (Fig.5)

- (a) Insert the Spring into the Exhaust Cover.
- (b) Insert the Spring into the concave of the Bushing PF3/8 of the Belt Sander.
- (c) Insert the convex of the Exhaust Cover into the groove of the Bushing PF3/8.





Fig.5

5-3. Attaching the Handle (B-30CL) (Fig.6)

Screw the Handle in the side of the Guard.



B-30CL

Fig.6

6. HOW TO OPERATE THE TOOL

⚠ Warning

- When sanding, always wear protective glasses and respiratory protection: Microscopic dust and abrasive particles that fly off the workpiece may cause eye or respiratory injury or both.
- Before you change or adjust the tool or parts, always disconnect the air supply hose.
- Never touch the moving parts in operation.

6-1. Start and Stop (Fig. 7)

- Check to see that the Throttle Lever is in the OFF position.
Then connect the hose to the Belt Sander.
- Holding the Belt Sander:
 - Push the Lock Lever down and behind,
 - Grasp the Throttle Lever.The Belt Sander starts running.
- When you release the Throttle Lever, it automatically returns to the OFF position.




Fig.7

6-2. Adjusting the Rotation Speed (Fig. 8)

The desired number of rotation between maximum Rotation Speed and minimum Rotation Speed is obtained by turning the groove of Valve clockwise or counter clockwise with screwdriver.

Maximum Rotation Speed

Position the groove of Adjust Valve horizontal to main body.

Minimum Rotation Speed

Position the groove of Adjust Valve vertical main body.




Fig.8

6-3. Tracking Adjustment (Fig. 9)

- B-10CL, B-20CL, B-20CL-A


Loosen the Hex. Socket Set Screw with a Hex. Socket Screw Key as shown in Fig.9, and adjust the adjusting Screw so as the abrasive Belt to run on the center of Idle Pulley. Tighten the Hex. Socket Set Screw with Hex. Socket Screw Key after the adjustment.

You need not make this tracking adjustment when you have an optional 6 mm wide Bracket 6 Assembly (applicable to B-10CL only).


- B-30CL

Loosen the Hex. Socket Head Cap Screw, Fig.9 with a Hex. Socket Screw Key.


Turn the Hex. Socket Head Cap Screw clockwise or counterclockwise with the accessory Hex. Socket Screw Key in order to make the abrasive belt run on the center of the idle pulley.



B-10CL



B-30CL, B-20CL-A



B-30CL

6-4. Sanding Operation

⚠ Warning

- Do not press the Abrasive Belt too hard upon the workpiece. If you do so, the Abrasive Belt may break.
- When using a non-woven Belt, do not use the Offset Bracket. If you do so, the Belt may come Off, causing personal injury.

For deburring operation, an Offset Bracket (optional) is to be used.

In this application, the Abrasive Belt will be brought into light contact with the workpiece somewhere in between the Idle Pulley and Offset Bracket.

For Sanding operation, the Offset Bracket will be removed and a Shoe will be used. The Abrasive Belt will be brought into light contact with the workpiece where the Shoe extends.


6-5. Changing the Abrasive Belt

⚠ Caution

- Before servicing, turn the Throttle Lever OFF and disconnect the hose from the Belt Sander.
- When the Abrasive Belt has an arrow marking on its inner face, see to it that you set it to the same direction in which the Belt Sander turns (there is a marking on the Guard), as well. It is dangerous to mount it wrong way for the Abrasive Belt may break prematurely.
- Do not press the Push Button without a Abrasive Belt mounted unless it is absolutely necessary to do so, for it may cause equipment failure.
- When changing the Abrasive Belt, remove dust and abrasive particles from the Drive Pulley area by air blow, etc.

a) B-10CL, B-20CL, B-20CL-A (Fig.10)

- 1) Loosen the Decorative Screw and turn the Belt Cover.
- 2) Keep pushing the Idle Pulley until the Tension Bar locks.
- 3) Change the Abrasive Belt with a new one. Press the Push Button to release Tension Bar locking.
- 4) Turn the Belt Cover to get it back to where it was. Tighten the Decorative Screw.



B-10CL, B-20CL, B-20CL-A

Fig.10

b) B-30CL (Fig.11)

- 1) Loosen the Decorative Screw and turn the Belt Cover.
- 2) Keep pushing the Idle Pulley until the Tension Bar locks.
- 3) Change the Abrasive Belt with a new one. Press the Shoe to release Tension Bar locking.
- 4) Turn the Belt Cover to get it back to where it was. Tighten the Decorative Screw.




Fig.11

6-6. Replacing the Shoe

a) B-10CL, B-20CL, B-20CL-A (Fig.12)

Remove the Shoe by loosening Pan Head Screw and replace the Shoe.




Fig.12

b) B-30CL (Fig.13)

Remove the Belt Cover, Loosen 2pcs, of the M6 cross-recessed Pan Head Screws with a screwdriver and replace the Shoe.




Fig.13

6-7. Replacing the Tension Bar

a) B-10CL, B-20CL, B-20CL-A (Fig.14)

- 1) Remove the Abrasive Belt. Press the Push Button. The Tension Bar will be unlocked.
- 2) Sufficiently loosen the Key Bolt and pull off the Idle Pulley Bracket while pressing the Push Button.
- 3) When reassembling the Tension Bar, assemble in reverse order.

b) B-30CL (Fig.15)

- 1) Remove the Abrasive Belt, the Belt Cover and the Shoe.

- 2) Sufficiently loosen the Key Bolt and pull off the Idle Pulley Bracket.
- 3) For mounting, adjust the groove on the Idle Pulley Bracket to meet the Key Bolt, insert it into the Guard, put the tip of Key Bolt into the groove and fix it so as the Idle Pulley Bracket not to be pulled off.




Fig.14




Fig.15

6-8. Replacing the Idle Pulley

(1) B-10CL (Fig.16)

Using a flatblade screwdriver and a Phillips Screwdriver, loosen the Flat Head Screw and pull the Idle Pulley Shaft off.

(2) B-20CL, B-30CL (Fig.17)

Using a flatblade screwdriver and a Wrench 10, loosen the Hex. Nut M6 and remove the Idle Pulley B Ass'y. When mounting the Idle Pulley B Ass'y, assemble in reverse order.

(3) B-20CL-A (Fig.18)

Using a flatblade screwdriver and a Hex. Socket Head Cap Screw, loosen the Flat Head Screw and pull the Idle Pulley Shaft off.




Fig.16




Fig.17




Fig.18

6-9. Offset Bracket (Optional)

The Offset Bracket is designed to utilize the spring action of Abrasive Belt, facilitating light-duty sanding applications, such as contoured surface sanding, deburring, etc.

- 1) Following the same procedure as Abrasive Belt replacement, remove the Abrasive Belt.
- 2) Remove the Shoe and mount the Offset Bracket Ass'y. For removal, refer to 6-7 Replacing the Shoe.
- 3) Install the Abrasive Belt and Belt Cover.




Fig.19

7. THREAD SIZE OF HOSE FITTING


The product comes with a metal fitting with R(metric) thread. Connect the Bushing R thread x NPT thread in the vinyl bag containing standard accessories, if you would like to have American NPT thread instead.

8. STORAGE AND MAINTENANCE

⚠ Caution

- When tool is not used, store it out of reach of children.

Avoid storing the tool in a location subject to high humidity. If the tool is left as it is used, residual moisture on the inside can cause rusting. Before storing, and after operation, oil the tool at the air inlet with machine oil ISO VG-10 and run it for a short time.




Offset Bracket 20 Ass'y (TB10192) for B-20CL,

9. ORDERING SERVICE PARTS

For further operational and handling information or for replacement of parts and components, contact the company from whom you purchased the tool or an authorized dealer.


In ordering parts and components give each part number, part name and quantity required.

Use only NITTO genuine parts.



Offset Bracket 30 Ass'y (TB08150) for B-30CL


(3) Finger Pad Ass'y (TB09938) for B-20CL for use




10. OPTIONAL PARTS

In addition to various kinds or grain sizes of abrasive materials and Sanding Belts, we have the following optional items to meet your diversified needs.

(1) Bracket 6 Ass'y (TB09996) for B-10CL for use with our narrow belt 6 mm in width, best suited for corner grinding or grinding in a narrow space. For mounting and removal, see 5-9 Replacing the Tension Bar.




Bracket 6 Ass'y
(TB09996)



Shoe 6
(TP14770)

(2) Offset Bracket Assembly
Offset Bracket 10 Ass'y (TB09997) for B-10CL





Overseas Affiliates / Offices

NITTO KOHKI U.S.A., INC.

46 Chancellor Drive, Roselle, Illinois 60172, U.S.A.
For Cuplas
Tel : +1-630-924-5959 Fax : +1-630-924-1174
For Machine Tools
Tel : +1-630-924-9393 Fax : +1-630-924-0303
www.nittokohki.com

NITTO KOHKI EUROPE GMBH

Gottlieb-Daimler-Str. 10, 71144 Steinenbronn, Germany
Tel : +49-7157-989555-0 Fax : +49-7157-989555-40
www.nitto-kohki.eu/

NITTO KOHKI EUROPE GMBH UK Branch

Unit A5, Langham Park Industrial Estate, Maple Road,
Castle Donington, Derbyshire DE74 2UT, United Kingdom
Tel : +44-1332-653800 Fax : +44-1332-987273
www.nitto-kohki.eu/

NITTO KOHKI AUSTRALIA PTY LTD

77 Brandi Street, Eight Mile Plains, Queensland 4113, Australia
Tel : +61-7-3340-4600 Fax : +61-73340-4640
www.nitto-australia.com.au

NITTO KOHKI (SHANGHAI) CO., LTD.

Room1506, Suite C, Orient International Plaza,
No.85 Loushanguan Road, Shanghai 200336, China
Tel : +86-21-6415-3935 Fax : +86-21-6472-6957
www.nitto-kohki.cn

NITTO KOHKI (SHANGHAI) CO., LTD. Shenzhen Branch

2005C Shenzhen ICC Tower, Fuhuasanlu 168,
Futian District, Shenzhen, Guangdong 518048, China
Tel : +86-755-8375-2185 Fax : +86-755-8375-2187
www.nitto-kohki.cn

NITTO KOHKI CO., LTD. Singapore Branch

10 Ubi Crescent #01-62, Ubi Techpark Lobby D, Singapore 408564
Tel : +65-6227-5360 Fax : +65-6227-0192
www.nitto-kohki.co.jp/e/nksb/index.html

NITTO KOHKI CO., LTD. Bangkok Representative Office

M&A Business Center, Q-House Convent Bldg.,
38 Convent Rd., Silom, Bangrak, Bangkok 10500, Thailand
Tel : +66-2632-0307 Fax : +66-2632-0308
www.nittobkk.com

NITTO KOHKI CO., LTD. India Liaison Office

3rd Floor, Building No.9-A DLF Cyber City, Phase-III,
Gurgaon, Haryana 122002, India
Tel : +91-124-454-5031 Fax : +65-6227-0192

NITTO KOHKI CO., LTD. Mexico Representative Office

OF1109 Torre Corporativo 1 Piso 11 Central Park Armando Birlain Shaffler
#2001 Col Centro Sur, Queretaro, Qro, C.P. 76090, Mexico
Tel : +52-442-290-1234

INSTRUCTION MANUAL

READ ALL INSTRUCTIONS BEFORE OPERATING THIS TOOL

ATRA ACE Model B-10CL, B-20CL, B-20CL-A, B-30CL
PROFESSIONAL TOOL