

JITOOL 제일타카(주)

Instruction Manual

Brad Nailer

1850A

1850N

MADE IN KOREA

Better Tools,
Better Works!



www.npower.com.vn

Tài liệu được tổng hợp bởi đội ngũ kỹ thuật của
NPOWER Bản quyền nội dung thuộc về công ty
JITOOL

Rev.Nov.2021.

Powered by **NAVITECH** | www.navitech.co

MODEL 1850A,1850N

KOREA

Page 3 to 21

ENGLISH

Page 22 to 33


EXPLODED DIAGRAM

Page 16,34,36

PART LIST

Page 17,35,37

각 부분의 명칭



부 속 품




오일



렌치

— 3mm —

— 4mm —



제품설명서

제품 박스 안의 부속품이 있는지 반드시 확인하여 주십시오.

목 차

	Page
각 부분의 명칭	3
안전상의 경고	5
사용 방법 및 주의사항	10
점검 및 손질	12
고장 및 제품 이상 시 조치방법	13
제품제원	14
사용조건	15
분해도	16
부품 리스트	17
제일타카 전국 A/S 지정점	18
제품 보증서	20

판매상 책임



본 공구를 판매하시는 모든 업주나 그 업종에 종사하시는 모든 종사원은 본 공구를 판매 하실 때 소비자에게 반드시 공구 사용 전 공구박스 안에 들어있는 제품 설명서(안전상의 경고, 사용방법 및 기타지시사항)를 읽고 숙지시킨 후 판매 하셔야 됩니다.
행할 것

고용주의 책임



본 공구를 사용하시는 모든 고용주는 공구 사용자 개인은 물론 주변 사람들의 안전과 공구의 올바른 사용을 위해 본 제품 설명서에 수록된 안전수칙과 기타 모든 지시사항을 준수해야 하며, 본 공구를 이용하는 모든 사람들에게 본 제품 설명서를 읽고 숙지시킨 후 공구를 사용할 수 있도록 주지시켜 주십시오.
행할 것

안전상의 경고

■ 사용상의 잘못으로 인한 안전사고를 미연에 방지하고, 제품을 보다 편리하게 이용할 수 있도록 주의 사항을 여러가지 그림표시로 알기 쉽게 나타내었습니다. 꼭 아래의 표시와 그 내용을 잘 이해하고 나서 설명서를 읽어 주십시오.

	위험	이 표시를 무시하고 잘못 사용하시면 사용자가 사망 또는 중상 을 입을 위험성이 있음을 나타냅니다.
	경고	이 표시를 무시하고 잘못 사용하시면 사용자가 중상 을 입을 가능성이 있음을 나타냅니다.
	주의	이 표시를 무시하고 잘못 사용하시면 사용자가 상해 를 입거나 물적손해 가 발생할 수 있음을 나타냅니다.

■ 각각의 그림표시에는 다음과 같은 의미가 있습니다.



일반적인 위험
경고, 주의



반드시 행할 것




일반적인 금지



위험

반드시 안전 인증기관으로부터 검증된 보안경, 귀마개, 안전모등 개인 보호장구를 착용하십시오.



작업시 공기압으로 인해 날아드는 각종 텁밥, 먼지, 기타 이물질들이나 취급 부주의로 튀어나오는 핀(네일, 스테이플 등)으로부터 사용자의 눈과 머리를 보호할 수 있는 보안경, 안전모를 착용하시고 사용 장소에 따라 밀폐된 장소나 이와 유사한 여건 속에서 발생되는 소음에 의해 청력의 장해를 가져올 수 있으므로 꼭 귀마개를 착용하십시오.

*일반 안경은 내 충격용 렌즈를 사용하지 않으므로 보안경이 아닙니다.

에어 콤프레서를 이용한 공기 이외의 어떠한 동력원도 사용해서는 절대 안됩니다.



본 공구는 안전 인증기관으로부터 검증된 에어 콤프레서에 의해 발생되는 공기압을 이용하여 작동되도록 설계, 제작되어 있으므로 이를 제외한 어떠한 종류의 가스(산소, 질소 등의 가연성 고압가스)를 사용하지 마십시오. 이 경우 공구의 고장은 물론 오작동 또는 폭발 등의 상황으로 사용자나 주변 사람에게 사망 또는 치명적인 상해를 입힐 수 있습니다.

적정한 공기압을 이용하여 사용하셔야 됩니다.



본 공구는 $4.0\text{kgf}/\text{cm}^2 \sim 7.0\text{kgf}/\text{cm}^2$ 공기압 범위 내에서 사용되도록 되어있으므로 사용 범위 내에서 공기압을 적절히 조정하여 사용하시고, 공기압이 $7.0\text{kgf}/\text{cm}^2$ 를 초과한 상태에서는 공구를 사용하지 마십시오.

이 경우 공구가 파손되어 공구의 수명을 단축 시킬 수 있으며 신체상 상해를 입을 수 있습니다.

안전상의 경고

⚠ 위험

폭발성 있는 물질 근처에서는 절대로 사용하지 마십시오.



가스, 신나, 휘발유 등 폭발성 물질 부근에서 사용하지 마십시오. 폭발성 있는 물질이 에어 콤프레서로 인입되어 공기와 함께 압축될 경우 폭발할 수 있으며 작업시 불꽃이 튀는 현상으로 화재를 일으킬 수 있습니다.
(가스가 차있는 공간에서 작업하지 마십시오.)

절대로 사람이나 동물을 향해 공구를 겨누어서는 안됩니다.



작업시 에어호스를 연결할 때, 에어호스가 연결된 상태일 때, 작업종료 후 에어호스를 분리할 때, 에어호스를 연결하지 않은 상태 등 어떠한 경우에도 절대로 사람이나 동물을 향해 공구를 겨누어서는 안되며, 작업대상 물체의 표면에만 발사해야 됩니다. 그렇지 않을 경우 사람이나 동물에게 치명적인 상해를 입힐 수 있습니다.

타정시를 제외하고는 절대로 방아쇠를 당겨서는 안되며, 특히 위치 이동 시 방아쇠를 당긴 채 공구를 운반하시면 안됩니다.



방아쇠를 당긴 채 이동 하시면 잘못 발사되는 네일, 핀, 스테이플등으로부터 작업자나 주변 사람에게 치명적인 상해를 입힐 수 있습니다.

⚠ 경고

에어 콤프레서의 에어를 공구의 에어 플러그에 정확히 연결하여 사용 하십시오.



경우에 따라 공구를 사용할 때나 사용한 후에 에어를 분리하고 난 뒤에도 공구 내부에 남아있는 잔여 공기에 의해 스스로 발사되어 상해를 일으킬 수 있으므로 에어의 연결 및 분리 시 정확하게 확인하고 사용하시기 바랍니다.

공구의 모든 부품, 소모품은 JITOOL 상표 순정 부품(네일, 핀, 스테이플등 포함)만을 사용하십시오.



그렇지 않을 경우 공구가 파손되어 공구의 수명을 단축 시킬 수 있으며 신체상 상해를 입을 수 있습니다.

☞ 중국 등의 유사품에 주의하십시오.

절대로 방아쇠를 당긴 채 네일, 핀, 스테이플 등을 장전해서는 안됩니다.



방아쇠를 당긴 채 네일, 핀, 스테이플등을 장전하지 마시고 에어 연결 후 네일, 핀, 스테이플을 장전하십시오. 작업 후에는 반드시 네일, 핀, 스테이플을 제거한 후 에어를 분리하십시오. 작업하지 않을 경우 방아쇠를 당기지 마십시오.

안전상의 경고

⚠ 주의

공구의 각종 조임 장치(볼트, 스프링류)가 꽉 조여져 있는지 반드시 확인하시고 사용하십시오.



행할 것 공구를 오래 사용하시면 작업시의 진동으로 각종 조임부가 느슨하게 풀릴 수 있습니다.
 공구를 사용하기 전에 반드시 조임부의 체결상태를 확인하시고 사용하십시오. 그렇지 않을 경우 공구의 고장으로 내구성 문제뿐만 아니라 오작동에 의해 상해를 입을 수 있습니다.

공구가 작동되지 않을 때 작업자 임의로 안전장치를 제거하거나 조작, 개조해 사용해서는 절대로 안됩니다.



금지 그렇지 않을 경우 공구의 고장, 오작동으로 상해를 입을 수 있습니다. 작동되지 않을 경우 반드시 가까운 A/S점에 문의 하시기 바랍니다.

안전한 작업을 위해 타정하고자 하는 대상물을 단단히 붙잡고 타정을 해야 됩니다.



행할 것 타정할 경우 공구의 반동으로 원치 않는 위치에 발사될 수 있으며 반동으로 인한 안전작업을 위해 대상물을 붙잡고 작업하십시오. 그렇지 않을 경우 치명적인 상해를 입을 수 있습니다.

공구를 사용하지 않을 때는 반드시 에어를 분리하고, 매가진(탄창) 내부를 비워야 합니다.



금지 작업 후 작업장을 떠나거나, 공구를 다른 곳으로 옮기거나, 공구를 다른 사람에게 인계하거나 또는 기타의 이유로 공구를 사용하지 않을 때는 반드시 에어를 분리하고, 매가진 내부에 들어있는 네일, 핀, 스테이플등을 꺼내서 아무 것도 장전되어 있지 않도록 해야 합니다

작업자가 서로 마주 본 상태에서 타정해서는 안되며 단단한 물체, 두께가 얇은 물체, 작업표면 모서리에 너무 가깝거나 경사면이 있는 부분, 이미 타정되어 있는 네일, 핀, 스테이플 위는 타정하지 마십시오.



금지 그렇지 않을 경우 네일, 핀, 스테이플등이 관통되거나, 빗나가거나, 튀어나가 상해를 줄 수 있습니다.

공구를 던지거나 떨어뜨리지 마십시오.



금지 공구에 충격을 가할 경우 치명적인 고장이 되어 오작동으로 인한 상해를 입을 수 있습니다. 또한 타정 이외의 용도(망치 대용)로 사용해서는 안됩니다

안전상의 경고

⚠ 주의

핀(네일, 스테이플)을 빼내는 공구의 총구에 못, 핀 등 기타 물건을 넣어 타정해서는 안됩니다.



치명적인 상해의 원인이 될 수 있습니다.

금지

네일(못)을 빼내는 공구를 사용할 경우 못 머리가 항상 바닥쪽 방향으로 향하게 놓고, 공구를 똑바로 세워서 사용하십시오.



그렇지 않을 경우 상해를 입을 수 있습니다

행할 것

네일(못)을 빼내는 공구로 나무에 박힌 못을 빼는 용도 이외에 철판에 박힌 리벳, 핀, 등을 빼내는데 사용해서는 안되며 휘거나 구부려진 못을 빼는데도 사용하지 마십시오.



공구의 파손, 고장이 날 수 있으며 상해를 입을 수 있습니다.

금지

올바르고 안전한 자세로 작업하여 주십시오.



불안정하고 무리한 상태의 작업은 손, 발, 허리 등에 상해를 줄 수 있습니다

행할 것

작업 장소를 옮길 때에는 공구의 가동을 멈추고 에어 호스를 분리하여 이동하십시오.



행할 것

- 공구의 모든 부품, 소모품은 JITOOI 상표의 순정 부품(네일, 핀, 스테이플 등 포함)만을 사용하십시오.
- 본 공구는 정신이상을 유발할 수 있는 약물 복용자, 정신이상자, 음주자가 사용해서는 안되며 특히 어린이, 노약자가 사용해서는 안됩니다.
- 공구의 보관은 직사광선을 피해주시고, 특히 어린이 손에 닿지 않게 하십시오.

사용 방법 및 주의사항

* 공구를 사용하기 전에 반드시 안전상의 경고를 읽어 주십시오.

준비사항



공구를 사용하기 전 반드시 개인 보호장구(보안경, 귀마개, 안전모등)를 착용하십시오.

행할 것



공구는 안전 인증 기관으로 부터 검증된 에어 콤프레셔의 적정한 압력
(4.0kgf/cm^2 ~ 7.0kgf/cm^2 범위 내)에서만 사용하십시오.

행할 것



공구의 안전장치, 방아쇠, 스프링의 작동, 조임 장치(볼트류, 스프링류등)가 이상이
없는지 확인하십시오.

행할 것



작업 시작 전 에어플러그 쪽에 타-카 전용오일을 3~4방울 정도 주입하여 주십시오.
(가능한 하루에 한 번 정기적으로 주유하십시오.)

행할 것



에어 호스의 길이는 5m 이내인지 확인해 주십시오.

* 손상, 파손된 호스나 연결부가 사용되고 있지는 않은지 반드시 확인하십시오.

행할 것



안전한 작업을 위해 공구를 사용 하기 전 작업자 주변의 사람들을 공구 사용 장소 주위
에서 되도록 멀리 떨어지게 한 후 작업하십시오.

작업중 파손, 파편 등으로 인해 주위에 있는 인체, 물체에 손상을 줄 수 있습니다.

행할 것

사용방법



사용전 매가진(탄창) 내부가 비어있는지 확인하십시오.

공구의 총구가 작업자나 주변 사람들에게 향하지 않도록 하시고 매가진(탄창) 내부가 비어
있는지 확인하십시오.

행할 것



제품의 기종에 맞는 네일, 핀, 스테이플을 정착하십시오.

매가진(탄창) 뚜껑을 열고 작업목적에 적합한 규격 (JITOOL 상표가 있는 순정품)의 네일,
핀, 스테이플등을 장전 한 뒤 뚜껑을 꽉 닫으십시오. 이때 네일, 핀, 스테이플등은 반드시
적정량만 장전하십시오. 그렇지 않을 경우 공구의 고장원인이 됩니다.

사용 방법 및 주의사항

* 공구를 사용하기 전에 반드시 안전상의 경고를 읽어 주십시오.



배기 공기에 의해 작업장소 주변의 먼지, 이물질 등이 날리는 것을 막기 위해 공구의 뚜껑(Cap)에 부착된 배기 커버를 사용자의 편의에 따라 그림과 같이 화살표 방향으로 조정하여 사용하십시오.

행할 것



작업을 끝낸 후 에어 호스를 분리해 주십시오.

행할 것



매가진 내부의 핀, 네일, 스테이플을 제거해 주십시오.

에어를 분리한 후 매가진(단창) 내부를 비운 뒤 먼지, 이물질, 기름 등의 오염 물질을 깨끗이 닦아 내십시오.

행할 것

주의



행할 것

- 공구를 사용하기 전에 공구에 수분이 인입되어 있을 수 있으므로 수분을 제거하신 후 에어를 연결하십시오.
(에어를 연결하기 전 공구의 에어플러그를 바닥 방향으로 향하게 세워 공구 내부의 수분을 제거하십시오.)
- 자연보다 높은 위치에서 작업할 때는 에어 호스에 충분한 여유 길이를 주시고 작업자는 공구가 떨어져 파손되는 것을 막기위해 안전줄을 공구에 설치 하십시오.
작업도중 공구를 높은 곳에서 떨어뜨릴 경우, 공구의 고장, 파손은 물론 충격에 의한 오발사등으로 상해를 입힐 수 있습니다.
- 작업시 공구를 사용하지 않는 다른 한손은 탄정 목표지점으로부터 최소한 20cm 이상 거리에 두는 것이 좋고, 얼굴이나 신체의 다른 부위 가까이에서 사용하지 마십시오.
너무 가까이 작업하시면 네일, 핀, 스테이플이나 먼지, 이물질등이 튀어나오는 경우가 있어 상해를 입을 수 있습니다.
- 에어 콤프레서와 공구 연결장치 사이에 반드시 에어 필터를 부착하여 사용하십시오.
습기가 많은 상태이거나 또는 이물질이 인입 된 에어 콤프레서는 공구의 고장을 물론 작동이 제대로 되지 않을 수 있습니다. 반드시 이물질을 걸을수 있는 필터를 부착하십시오.
- 작업을 종료하거나 공구를 사용하지 않을 때는 반드시 에어호스를 분리하십시오.
- 공구를 보관하실 때는 깨끗하게 청소한 후 공구 박스에 넣어 건조하고 서늘한 곳에 보관하십시오. 특히 어린이의 손이 닿지 않는 곳에 보관 하십시오.
 - 하절기 : 작사광선, 일폐된 공간은 피해 주십시오.
 - 동절기 : 난로주위, 추운 장소는 피해 주십시오.

사용 방법 및 주의사항

※ 공구를 사용하기 전에 반드시 안전수칙을 읽어 주십시오.

주의



- 공구에 네일, 핀, 스테이플 등이 장전되지 않은 채 공터로 타정하시면 안됩니다.
공터로 타정하게 되면 내부의 범퍼가 손상되어 원활한 작동이 되지 않을 수 있습니다.
- 공구를 네일, 핀, 스테이플 등의 타정 외에 다른 목적으로는 절대 사용하지 마십시오.
금지

본제품은 드라이버 가이드와 가이드커버(총구에 해당)의 결합구조가 볼트로 체결되어 있으므로, 사용 도중 네일의 깜현상(jam)이 발생될 때 강제로 네일을 빼내지 마십시오. 반드시 다음의 방법으로 빼내 주십시오.

- (1) 손가락을 방아쇠로부터 떼낸다.
- (2) 매가진으로부터 잔량의 핀, 네일, 스테이플 등을 제거한다.
- (3) 공구로 부터 에어의 연결을 분리 시킨다.
- (4) "L"렌치(3mm)를 사용하여 볼트를 풀어 가이드커버를 완전히 분리한 후 깜현상(jam)이 발생된 핀을 제거하고 위와 반대의 순서로 재조립 한다.



행 할 것



주의 : - 깜 현상으로 핀을 제거할 경우 공구를 작업자나 주변 사람을 향해서는 안됩니다.
- 깜현상으로 핀을 제거한 후 재결합을 할 경우 볼트를 확실하게 꽉 조인 후 다른 부위의 이상이 없는지 꼭 확인하시기 바랍니다.
- 본래의 상태대로 완전히 재결합이 되었는지 확인한 후 에어를 연결 하십시오
- 공구의 재결합 과정 중 이상이 발생되어 재결합이 불완전하거나 불가할 때는 즉시 가까운 A/S 지정점에서 완전한 수리를 받은 후 사용하십시오.

점검 및 손질

■ 공구의 사용 후에는 안전하고 깨끗이 보관하십시오.

⚠ 주의



행할 것

- 점검, 손질 시에는 에어의 연결을 분리시켜 주십시오.
- 에어의 연결을 분리한 후에는 매개진(단창) 내부의 핀, 네일, 스테이플 등을 제거하십시오.
- 반드시 장갑을 끼고 점검 및 손질하여 주십시오.

⚠ 경고



금지

- 분해, 수리, 개조를 하지 마십시오.
-당사 서비스 지정 대리점에서 지정한 요원 이외의 사람은 분해하거나 수리, 개조하지 마십시오. 이상작동으로 상해를 입을 수 있습니다.



행할 것

- 사용 전•후에 항상 점검해 주십시오.
 - 공구의 모든 조임 장치가 단단하게 제결되어 있습니까?
(지속적으로 사용할 경우 반발에 의해 조임이 느슨해질 수 있으므로 장치는 항상 단단히 제결되어야 합니다.
그렇지 않을 경우 공구의 고장, 파손 또는 오작동을 발생시킬 수 있습니다.)
 - 공구의 공기압이 알맞게 설정되었습니까?
(4.0kgf/cm²~7.0kgf/cm²)
 - 작업하기 위한 안전 보호 장구를 착용 하셨습니까?
(보안경, 귀마개, 안전모 등)
 - 안전장치와 방아쇠가 원활하게 작동합니까?
(작동이 원활하지 않은 경우에는 공구를 사용하지 마시고 가까운 A/S 지정점에서 점검을 받아야 합니다.)
 - 부품이 마모되지는 않았습니까?
(핀, 네일, 스테이플등이 발사 되는 가이드 부와 피스톤 블레이드가 심하게 파손되면 오작동을 일으켜 상해를 입을 수 있습니다. 반드시 A/S 지정점에서 점검을 받아야 합니다.)



행할 것

- 사용후에 올바르게 손질하여 주십시오.
 - 최적의 조건으로 공구를 사용하기 위해서 타카 전용 윤활제를 주입하십시오.
(공구를 사용하기 전에 에어플러그 쪽의 구멍에 공구전용 윤활제를 3~4방울 정도 주입한 뒤 에어호스를 연결하십시오. 공구전용 윤활제 이외의 휘발유, 신나, 경유 등 다른 물질을 윤활제 대용으로 사용하시면 폭발의 위험성이 있으며 부품에 손상을 줄 수 있습니다.)
 - 공구의 보관은 깨끗하게 청소한 후 공구 박스에 넣어 두시고 건조하고 서늘한 곳에 보관하십시오. 특히 어린이 손이 닿지 않는 곳에 보관 하십시오.
 - 손질이 끝나면 부품을 정확히 조립하십시오.
(정확한 조립이 되지 않으면 오작동으로 상해를 입을 수 있습니다.)

고장 및 제품 이상 시 조치 방법



제품에 이상이 있을 때는 서비스를 의뢰하기 전에 다음 사항을 확인하여 주십시오.

행할 것

구분	증상	조치방법(서비스 의뢰)
방아쇠를 당기지 않을 경우	방아쇠에서 에어가 새어 나온다.	방아쇠를 풀어서 이 물질을 제거해 주고 오링이 마모되었을 경우 교환 한다.
	가이드 쪽으로 에어가 새어 나온다.	실린더 가이드 오링을 교환한다. 실린더 오링을 교환한다.
	뚜껑 쪽에서 소리가 난다.	뚜껑 오링을 교환한다.
		헤드 밸브를 교환한다.
		스프링의 유무 및 장착을 확인한다.
방아쇠를 당길 경우	가이드 쪽에서 새는 소리가 들린다.	범퍼의 이 물질을 제거해준다. 범퍼 파손시 교환해 준다.
	뚜껑에서 이상한 소리가 들린다.	뚜껑 씰을 살펴보고 스프링 파손시 교환한다.
	작동이 전혀 안된다.	뚜껑을 풀고 헤드 밸브 작동을 확인하고 작동이 안될 경우 헤드 밸브 오링을 교환한다.
		에어 플러그를 교환해 준다.
		밸브세트를 교환해 준다.
작동을 했을 경우	피스톤 후진 시 이상한 소리가 난다.	헤드밸브를 교환한다. 피스톤 오링을 교환한다.
	핀이 2~3개씩 남는다	푸셔 스프링을 교환한다.



조치방법의 수리는 소정의 교육 훈련을 이수한 자격 소지자만이 수행할 수 있습니다.

행할 것



수리를 할 때는 반드시 JITOOI 상표가 있는 순정부품을 사용해야 됩니다.

행할 것



기타 문의 사항은 가까운 A/S 지정점에 문의하십시오.

행할 것




수명이 다된 공구를 처분 할 때는 환경에 오염되지 않도록 본 서비스 지정점에 보내어 폐기하도록 해야 합니다.

행할 것

제품 제원

형식명	18GA. 50mm Brad Nailer	18GA. 2" Brad Nailer
모델명	1850A (mm Type)	1850N (inch Type)
SIZE(mm)	244 X 244 X 62	244 X 244 X 62
중량	1.39 (kg)	1.39 (kg)
사용 공기압	4.0kgf/cm ² ~ 7.0 kgf/cm ²	4.0kgf/cm ² ~ 7.0 kgf/cm ²
에어 플랜지 접속경	Ø 1 / 4" AIR HOSE	Ø 1 / 4" AIR HOSE
매가진(탄창)용량	100 nails	100 nails
작용 NAIL 사양	15mm~50mm	19mm~50mm




사용 조건

사용압



4.0~7.0 kgf/cm²

못사양



1850A


1850N

반드시 규격(JITOOL순정부품)에 맞는 핀, 네일을 사용하십시오.

EXPLODED DIAGRAM OF 1850A

분해도

(REV:2021/10/05)



1850A (18GA. 50mm LONG. BRAD NAILER)

NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY
1	배기 카비	422-C-103	1	24	에어 플러그	CT64-B-005	1	48	가이드 카비 B	1850A-G-003	1
2	볼트 (M5x25L)	Z-05-250	4	25	플러그 캡	CT64-B-006	1	49	볼트 (M4x16L)	ZN-04-160	2
3	캡	1850A-C-001	1	26	그립	1850A-B-104	1	50	드라이버 가이드	1850A-G-001	1
4	캐스킷	1850A-C-102	1	27	밸브 세트	1850A-V-P001	1	51	칠판	F30-M-005	1
5	해드 밸브 실 A	422-H-007	1	28	밸브 플런저 오링	CT64-V-004	1	52	푸시	1850A-M-103	1
6	캡 스프링	422-H-006	1	29	밸브 플런저	1850-V-007	1	53	푸셔 스프링	1850-M-004	2
7	캡 오링	422-H-010	1	30	플런저 스프링	1850-V-009	1	54	마거진 A	1850A-M-001	1
8	해드 밸브 오링	1850-H-004	1	31	플런저 오링	CT64-V-008	2	55	마거진 B	1850A-M-002	1
9	해드 밸브	1850-H-201	1	32	플런저	1850-V-010	1	56	볼트 (M4x8L)	Z-04-080	1
10	해드 밸브 실 오링	1850-H-009	1	33	플런저 캡 오링	1013-V-011	1	57	스프링 외셔 (for M4)	W-04	1
11	해드 밸브 실 B	422-H-008	1	34	플런저 캡	1850-V-012	1	58	트원 니트	1850-M-012	2
12	칼라	1850-A-004	1	35	방아쇠 스프링	1013-T-006	1	59	마거진 앤드 캡	1850-L-101	1
13A	피스톤 세트	1850-P-P101	1	36	핀 스토퍼 오링	CT64-M-008	1	60	부싱	C174-L-007	2
13	피스톤	1850-P-P102	1	37	길 방아쇠	1850-T-001	1	61	볼트 (M4x12L)	ZN-04-120	2
14	피스톤 오링	1850-P-003	1	38	핀 가이드	1850-T-003	1	62	클릭 라버	C174-L-002	1
15	실린더	1850-A-001	1	39	방아쇠 판	422-T-008	1	63	클릭 라버 스프링	C174-L-004	1
16	실린더 오링	1850-A-005	2	40	속 방아쇠	1850-T-002	1	64	볼판 (Φ3x18L)	R-30-180	1
17	실린더 가이드	1850A-A-002	1	41	볼핀 (Φ3x14L)	R-30-140	1	65	브래킷	1850-M-106	1
18	실린더 가이드 오링	1665-A-005	1	42	볼트 (M5x22L)	Z-05-220	2	66	볼트 (M5x12L)	Z-05-120	1
19	범퍼	1850-A-003	1	43	가이드 카비 A	1850A-G-102	1	68	볼트 (M4x6L)	ZN-04-060	2
20	노출	F30-B-007	1	44	콘택트 암	1850A-S-002	1	69	락 니트 (for M5)	NN-05	1
21	바디	1850A-B-301	1	45	세이프티 라버	1850-S-111	1	70	푸셔 헬더	F30-M-013	2
22	엔드 컨 오링	422-B-003	1	46	볼트 (M4x10L)	Z-04-100	2				
23	엔드 캡	422-B-102	1	47	세이프티 가이드 카비	1850A-S-010	1				

**상기부품은 자사의 시정으로 인하여 변경될 수 있습니다.

(제작일 : 2021/10/05)

제일타카 전국A/S지정점

전국 서비스 센터	타카	콤프레사	보증공구	031-527-5452	남양주시 오남읍	0	0	
인천영업소	032-766-7490	남구 업진로	0	0	상신돌	031-528-1788	남양주시 오남읍	
서해영업소	031-683-5022	광택시 청북면	0	0	아리랑공구	031-511-9924	남양주시 화도읍	
대전영업소	042-636-0040	동구 구도동	0	0	가나엔지니어링	031-594-0034	남양주시 화도읍	
광주영업소	062-526-8295	북구 경양로	0	0	공구백화점	031-666-0945	동두천시 생연동	
대구영업소	053-421-8294	서구 문화로	0	0	명동돌공구	032-657-7686	부천시 소사구	
경남영업소	055-329-3755	김해시 분성로	0	0	종합공구백화점	031-752-3532	성남시 수정구	
부산영업소	051-303-9800	사상구 모덕로	0	0	청계공구	031-752-0938	성남시 중원구	
서울	타카	콤프레사	제일돌공구	031-756-8609	성남시 중원구	0	0	
무릉철물	02-479-3455	강동구 성내동	0	0	대광기기상사	031-295-0945	수원시 권선구	
제일종합공구	02-479-1989	강동구 천호2동	0	0	신한돌공구	031-224-2743	수원시 팔달구	
신한공구	02-474-9695	강동구 천호동	0	0	평종합공구	031-241-2853	수원시 팔달구	
미래산업공구	02-980-0483	강북구 미아동	0	0	제일종합공구	031-257-2909	수원시 팔달구	
원중구	02-903-0989	강북구 수유동	0	0	동명종합공구	031-252-3809	수원시 팔달구	
전공구	02-882-0989	광악구 산림동	0	0	시화풀드	031-430-4959	시흥시 경왕동	
금호공구	02-877-9933	관악구 은천동	0	0	태영공구	031-408-0949	안산시 이동	
준명YNS	02-455-0989	광진구 구의동	0	0	안성공구	031-671-3809	안성시 인자동	
미강시스템	02-2625-7291	구로구 구로동	0	0	인덕공구	031-424-2611	안양시 동안구	
동밀상사	02-2634-8516	구로구 구로동	0	0	월밀공구	031-479-0598	안양시 동안구	
수리공구	02-806-8338	금천구 시흥동	0	0	진양공구	031-372-9647	오산시 원동	
영진공구	02-744-0975	동대문구 대신평화동	0	0	대교종합공구	031-775-0904	양평군 양평읍	
장안종합공구	02-2215-0909	동대문구 대신평화동	0	0	동부종합공구	031-282-0900	용인시 기흥구	
천안종합상사	02-2247-1388	동대문구 천안동	0	0	동부종합공구	031-338-0946	용인시 모현면	
신일공구	02-572-5092	서초구 양재1동	0	0	수지종합공구	031-262-0095	용인시 수지구	
임개공구	02-576-0989	서초구 양재동	0	0	영일공구	031-871-0109	의정부시 가능동	
성원회스너	02-498-4209	성동구 송정동	0	0	진영공구	031-844-0889	의정부시 의정부동	
해광종합공구	02-2602-0942	양천구 신월1동	0	0	유원상사	031-638-0967	이천시 서음동	
공항종합공구	02-2695-0989	양천구 신월동	0	0	신화건설공구	031-634-0915	이천시 중리동	
기산종합공구	02-908-0949	양천구 중앙로	0	0	제일돌 마트	031-653-0945	광택시 신대동	
범진철물	02-844-2121	영등포구 대림3동	0	0	이서E&T	031-686-8806	광택시 표승읍	
강남돌공구	02-2676-1127	영등포구 영등포동	0	0	공구장사	031-794-0904	하남시 덕풍동	
다되는공구	02-383-0989	은평구 조동동	0	0	민성종합공구	031-8015-0981	화성시 반송동	
유일공구	02-384-0909	은평구 억관동	0	0	현대기계공구	031-356-0944	화성시 매향면	
청개공구	02-309-1980	은평구 억관동	0	0	인천종합역시			
녹번종합공구	02-386-9801	은평구 응암동	0	0	타카	콤프레사		
서원콤프레사	02-2273-8965	중구 수표동	0	0	강화군 강화읍	0	0	
삼익돌공구	02-313-7516	중구 증평동	0	0	힐제 공구	032-542-5365	계양구 계산동	
대영상사	02-2208-0953	중랑구 연희동	0	0	유럽공구	032-888-0991	남구 숭의동	
OK공구	02-494-0989	중랑구 상봉동	0	0	아틀스	032-889-2209	남구 숭의동	
경기도	타카	콤프레사	도일종합공구			도일종합공구	032-872-2109	남구 주안동
창대공구	031-559-3201	가평군 가평면	0	0	한진공구	032-428-1810	남동구 간석동	
제일타카(고양)	031-962-0935	고양시 덕양구	0	0	대일기계	032-421-8141	남동구 구珥동	
건아공구	031-919-0409	고양시 일산구	0	0	상일종합공구	032-422-0909	남동구 구珥동	
문화공구	031-969-0988	고양시 일산동구	0	0	금풍교역	032-571-0275	동구 송림동	
알파종합공구	031-903-0946	고양시 일산동구	0	0	영진상사	032-589-0902	동구 송림동	
공구119	031-769-5409	광주시 장지동	0	0	마니토상	032-763-2886	동구 송림동	
근품공구	031-798-0948	광주시 초량면	0	0	진성기계공구	032-588-1962	동구 송현동	
세정종합상사	031-797-6166	광주시 초량읍	0	0	부풀철물	032-529-8974	부평구 부평동	
근풀종합공구	031-768-0808	오포읍 오포대로	0	0	공구장사	032-512-0904	부평구 부평동	
선진공구	031-982-3509	김포시 대곶면	0	0	대화종합역시			
동신종합공구	031-998-4909	김포시 양촌면	0	0	타카	콤프레사		

제일타카 전국A/S지정점

오정공구	042-636-3477	대덕구 오정동	0	0	보성종합공구	053-556-9875	중구 달성로	0	0
한양공구상사	042-634-3309	대덕구 오정동	0	0	선산목공	053-426-9430	중구 동인동1가	0	
와와풀	042-625-8916	동구 둘대전로	0	0	경산목공백화점	053-424-5818	중구 태평로	0	0
동보종합목공	042-250-1048	동구 원동	0	0	영남공구상사	053-422-8609	중구 태평로3기	0	0
대만종합공구	042-528-0949	서구 도마2동	0		부산광역시		타카	콤프레사	
현대종합공구	042-531-4470	서구 도마동	0	0	진흥목공구	051-971-6689	강서구 강동동	0	
충 청 도		타카	콤프레사	진흥기계공구		051-634-5800	동구 법일2동	0	
대룡공사	041-753-4270	금산군 금산읍	0		대룡종합공구	051-554-2081	동래구 낙민동	0	
현진공구	041-936-0955	보령시 둘대동	0		세원종합상사	051-311-0648	사상구 강진동	0	
내경공구	041-667-5003	서산시 잠은동	0	0	대우철물공구	051-245-2909	서구 도성동2가	0	
제일공구	041-665-0106	서산시 운문동	0	0	24시공구	051-865-0634	연제구 연산동	0	
이전종합상사	043-881-0989	을성군 갑작면	0		영은교역	051-315-6658	강서구 유동단지1로	0	0
삼거리공구	043-646-0908	제천시 화산동	0	0	돌테크	051-522-9948	금정구 금사동	0	0
제일돌공구	041-551-1525	천안시 사직동	0	0	자주목공구	051-743-5889	금정구 전진동	0	0
성일종합상사	043-215-0944	청주시 상당구	0		세월종합상사	051-311-0648	사상구 강진동	0	0
명성동공구	043-215-0988	청주시 상당구	0	0	경 상 도		타카	콤프레사	
개량종합상사	043-259-8171	청주시 상당구	0	0	공구마트	055-633-8983	거제시 경명동	0	
선일종합상사	043-234-3609	청주시 흥덕구	0		제일목공구체험	055-325-0988	김해시 분성로	0	0
광주광역시		타카	콤프레사	광명파워공구		055-242-0990	마산시 합포구	0	0
유성정밀금속	062-522-9507	북구 우산동	0		벽방종합공구	055-833-1789	사천시 돌금동	0	
한국기업	062-511-3700	북구 운암2동	0		동신종합공구	055-382-5657	양주시 남부동	0	
탑첨물공구	062-526-2609	북구 운암동	0		광양돌집	055-741-4291	진주시 불곡동	0	
제일첨물공구	062-527-0977	북구 증평동	0		남강철물	055-762-1672	진주시 성대동	0	0
신성돌테크	062-369-3651	서구 디립동	0	0	제양산업공구	055-759-0989	진주시 상평동	0	
리오	062-513-4568	서구 동천동	0		신흥철물	055-757-4007	진주시 상평동	0	
철오공구	062-603-0942	서구 매월동	0	0	청계천공구	055-757-6755	진주시 하대동	0	
세광공구	062-603-3111	서구 매월동	0	0	신흥공구	055-294-0966	창원시 마산회원구	0	
화정돌공구	062-364-3370	서구 양동	0	0	태양목공구	055-297-3544	창원시 마산회원구	0	
영재철물	062-366-0989	서구 천변좌로	0		육일공구사	055-237-6109	창원시 의창구 명사동	0	
전 라 도		타카	콤프레사	성보기기		055-265-4001	창원시 의창구 불영동	0	
형제공구백화점	061-743-4470	순천시 덕암동	0		진해종합공구	055-542-0956	창원시 진해구 경화동	0	
명성철물장식	061-741-4456	순천시 풍덕동	0		삼일공구	055-583-3109	함안군 가야읍 밭산리	0	
동성철물건제	061-651-6062	여수시 덕동	0		동일종합상사	053-815-1474	경산시 중방동	0	
세계종합공구	061-682-8970	여수시 화산2길	0		종합상사기광	054-773-1038	경주시 외동읍모찌리	0	0
남한공구	063-564-0409	고창군 고창읍	0		동보종합상사	054-777-0948	경주시 한화로	0	
한일건설공구	063-544-1254	김제시 신길길 18	0	0	계영김천센터	054-431-0985	김천시 아포대로 32	0	0
제일기계공구	063-636-0989	남원시 금동	0	0	하나기업	054-933-0620	성주군 선남면 선원리	0	
반도공구	063-842-9694	의산시 평화동	0		천경제일종합공구	054-920-0989	칠곡군 다산면 고희리	0	0
제일공구	063-842-2670	의산시 평화동	0	0	포항자재센터	054-281-9788	포항시 남구 대창동	0	0
종합철물점	063-243-2315	전주시 덕진구	0	0	보쉬돌핑동보철물	054-244-2085	포항시 북구 죽도동	0	0
돌암돌공구	063-251-2723	전주시 완산구	0		강 월 도		타카	콤프레사	
한진기계공구	063-531-0860	정읍시 연지동	0	0	대광기계공구	033-642-4161	강릉시 옥천동	0	0
대구광역시		타카	콤프레사	강릉기계공구		033-648-8909	강릉시 교동	0	
화신천연기기	053-253-2078	중구 복성로2가	0	0	제 주 도		타카	콤프레사	
금강엔진	053-256-8281	중구 서야동	0	0	제주돌공구	064-758-0234	제주시 용담1동	0	0
해동건설기계	053-252-7678	중구 인교동	0	0	용산공구마트	064-763-0310	서귀도시 일주동로	0	
명성동센터	053-632-3182	달서구 진천동	0		공구이마트	064-702-0982	제주시 사령2길	0	
에어샵	053-604-0907	북구 산격동 1629	0						
남수철물	053-425-1689	북구 철성1가	0						
신영목공종합	053-423-8465	북구 철성2가	0						
형제종합철물	053-431-3778	북구 철성시장로	0	0					REV.2016.1

제품 보증서

- 제일타카(주)에서 제작된 제품(Nailer, Stapler, Pinner 등)은 최상의 재료와 최고수준의 제작기술을 활용하여 설계·제작되었습니다.

제품 보증 기간내에 발생된 고객 불만족 사항에 대해서는 제일타카(주)가 인정하는 검사자(해당 A/S 실무 담당자 또는 그 이상자)의 기술 검토를 통해 재료의 결함, 부품의 결함, 제작·기술상의 결함으로 결정된 경우에 한하며 무상으로 수리 및 부품 교체의 서비스를 받을 수 있습니다.

- 고객 만족도 100% 달성이라는 품질 목표로 품질 제일주의를 지향하고 있는 제일타카(주)의 제품 보증 기한을 아래와 같이 기술하여 소비자의 편익을 제공하고자 합니다.

1)부품 보증(피스톤 세트, 피스톤 오링, 헤드 벨브 오링)

-최종 사용자가 구입한 날로부터 45일

2)본체 주조물(Body, Cap)

-최종 사용자가 구입한 날로부터 1년

3) 기타 부품

-최종 사용자가 구입한 날로부터 90일

4)무상수리 및 부품 교체 서비스 조건

a. 정결하고 건조한 규정된 공기압만을 사용한 경우 ($4.0\text{kgf/cm}^2 \sim 7.0\text{kgf/cm}^2$)

b. 제품 설명서에 명기된 내용(안전 수칙, 사용 방법 및 주의사항 등)을 준수하여 사용한 경우

c. 최종 사용자가 구입한 제품이 보증 기간 내에 있음을 입증할 수 있는 구매 영수증이나 기타 증빙서류를 첨부하여 본사 지정 A/S 센터에 제품을 반납한 경우

단, 운송비는 최종 사용자가 선불 지급처리하고 소비자 귀책여부에 따라 자사에서 운송비지급

위 사항들이 모두 만족된 조건하에서 무상 서비스를 받을 수 있으며 제품을 임의로 개조하여 사용하였을 경우 또는 JITOOL 순정 부품을 사용하지 않았을 경우 무상 서비스를 받을 수 없습니다.

- 문서로 명시하지 않은 그 외의 보증은 어떠한 경우라도 적용되지 않으며 보증 실패(해당 A/S 실무 담당자 불인정)로부터 초래될 우연적, 필연적, 직접적, 간접적 배상에 대해서는 책임지지 않습니다.

- 이 제품의 구매자에 대한 제일타카(주)의 제품 보증 위반, 계약위반, 불법 행위로부터 발생하는 손실이나 손해에 대한 제일타카(주)의 책임에 대한 의무는 권리 채무를 발생시킨 본 제품의 가격을 초과할 수 없습니다.

- 이 제품의 사용과 관련된 모든 책임은 상기 명시된 보증 기간의 만료와 동시에 소멸됩니다.


제품 보증 카드

모델명			Serial No.	
구입처	상호명		구입일자	
	소재지		Tel.	
구매자	성명		Tel.	
	주소			

JITOOL 제일타카(주)

*공구 구입 즉시 제품 보증 카드를 작성해 주시기 바랍니다.

예 모



CONTENTS (INDEX)

	Page
1. Safety Instructions —	23
2. Specifications and Technical Data —	26
3. Instructions for Operation —	28
4. Maintenance and Inspection —	30
5. Service and Repairs —	31
6. Maintenance Chart & Operator Troubleshooting —	32

Responsibility of Distributor



When selling this tool, all the salespersons and distributors who deal in the tool must make sure that a consumer reads and understands the instructions before using it.

Responsibility of Employer



All the employers who use this tool must observe safety regulations and all the other guidelines in this manual to keep a user and those around him or her safe and to use it correctly, and must have a user read and understand the instructions before using it.

DANGER	
	<p>Dangerous and improper use of the nailer can result in death or serious injury. This manual features safety information for your safety. Be sure to read and understand this manual before using this tool. Please keep this manual well to allow other workers to read it before using this tool.</p>

DEFINITIONS OF SIGNAL WORDS

DANGER

Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

WARNING

Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury, or may cause a damage to the tool.

1. SAFETY INSTRUCTIONS

DANGER

1. Be sure to put goggles on before operation.



Since a nail fired wrongly through careless handling can spring out or you are always exposed to danger that can be caused by dust and extraneous substances dispersed by exhausted air, you must always wear goggles for operation. Goggles should meet requirements of **ANSI Z89.1-1997** and be able to protect both the front and the sides. An employer has responsibility for having workers and all the other persons wear protective equipment in a workshop.

2. Put on hearing protective equipment in certain working environment.




In working environment exposed to loudness which may result in hearing loss, an employer (management) must provide hearing protection equipment to a user and others in the workshop and a worker must wear it if necessary.

3. Never use any power source but compressed air.




As this tool is designed and manufactured to operate using air pressure that is generated by an air compressor authorized by an safety certification authority, you cannot use any kind of gas—combustible gases such as oxygen and acetylene—except this. Otherwise, it may not only cause mechanical trouble but also malfunction or explosion, resulting in infliction of fatal injury on a user or those around him or her.

4. Use it within the optimum range of air pressure.



This tool is designed to operate within a range of pressure between 60 psi and 100 psi (or between 4 kgf/cm² and 7kgf/cm²). Connect this tool to a pressure-controllable device so that you can work under fixed pressure. When operating this tool, never use it under pressure of 100 psi (or 7kgf/cm²) and over. This tool can blow up when connected to pressure higher than 175 psi (or 12 kgf/cm²).

5. Don't use it near inflammables (combustibles).



Never operate this tool near inflammables (such as thinner and gasoline). Combustible gas from such materials can be sucked into a compressor and compressed together with air, possibly resulting in explosion.

6. Be careful not to aim or fire it toward yourself or any other person in any case.



You should be careful not to aim it toward yourself or any other person in any case whether the tool is loaded with nails or not. Then, even if malfunction or undesired firing occurs, you can minimize damage caused by the fired nail. Otherwise, it may result in serious injury.

7. Never touch the trigger except when this tool is operated for work.

Never touch the trigger except when air is connected to this tool, which operates for work. It is especially very dangerous to change the position or move around during operation with your finger fixed on the trigger, and you may not do any similar action. Otherwise, possible carelessness may result in infliction of serious injury on a user or those around him or her.

⚠ WARNING

8. Connect a proper connector to this tool correctly.

The connector for this tool should never have pressure kept remaining when air supply is cut off. If an improper part is applied, then the tool can operate due to pressure left within it even after the air line is disconnected, possibly resulting in injury.

9. Disconnect the air line and empty the nails out of the container in case hat the tool isn't used.

Be sure to cut off air supply and empty the nail container when the work is completed or when you move to another workshop, maintain, disassemble, or repair this tool, or clear jam. Make sure that the air line is disconnected in loading the container with nails again.

⚠ CAUTION

10. Make sure that each fastener is locked tightly.

The tool can be damaged if you use it with each fastener loosened, or screws or bolts assembled wrongly. Make sure that all screws and bolts are assembled correctly and tightly before using the tool.

11. Never let a worker remove or manipulate a safety device, or recompose the tool at his or her discretion.

If you remove a safety device, or manipulate or recompose the tool at will, it can cause a drop in performance and breakdown of the tool and result in injury due to mechanical trouble and malfunction.

12. Be sure to disconnect the air line and empty nails out of the container if the tool is not used.

You must disconnect the air line and empty the nail container when the work is completed or suspended, when you go out of a workshop, when you move or transfer the tool, or on other occasions.

13. Stick the muzzle correctly to the target plane for nailing.

If correct nailing is not implemented on the target plane, the fired nail can spring out, possibly resulting in injury.

14. You are prohibited from using the tool for other purposes than nailing and from throwing or dropping it.

The resultant shock can cause damage to main parts or malfunction, possibly resulting in injury.

15. Never nail hard or thin objects, an edge of the target surface, or a nailhead already driven.

Otherwise, the nail fails to be driven in but springs out, thus inflicting an injury on a worker or those around him or her.

16. Conduct operations in an upright and safe position all the time.

Long-time work in an unstable and wrong position may put excessive stress on the body, possibly resulting in an injury.


17. When the temperature falls below zero, it is important to note that you should keep the tool warm in a safe and convenient way.

If you fail to do this, make the tool get warm according to the following procedure.

- ① Control air pressure in the range of 40psi to 70psi.
- ② Remove all the nails loaded in the tool.
- ③ Connect the air line to the tool and try mock nailing.
 - Keep pressure low enough to operate the tool in a proper way.
 - Operate it slowly to let the actuator get warm.
 - Piston operation helps bumper and O-ring maintain the original elasticity.

2. SPECIFICATIONS


1. Name of Parts



2. Specifications of Nailer

Model	1850A (mm Type)	1850N (inch Type)
Dimensions (L x H x W)	9-5/8" x 9-5/8" x 2-7/16" (244mm x 244mm x 62mm)	9-5/8" x 9-5/8" x 2-7/16" (244mm x 244mm x 62mm)
Weight	3.06 lbs. (1.39 kg)	3.06 lbs. (1.39 kg)
Operating Pressure	58 ~ 100 psi (4 ~ 7 kgf/cm ²)	58 ~ 100 psi (4 ~ 7 kgf/cm ²)
Nail Capacity	100 Nails	100 Nails
Nail Spec	15mm ~ 50mm	3/4" ~ 2"
Air Inlet	1/4" NPT	1/4" NPT

3. Fastener Specifications



4. Applications

- * Finish and Trim (interior and exterior)
- * Decorative Trim
- * Cabinets
- * Case Backs
- * Molding
- * Mirror and Picture Frames
- * Paneling

3. Instructions for Operation

<Instructions for Operation>

※ Be sure to read the safety instructions before using this tool.

Preparations

1. Be sure to put on personal protective equipments—for example, goggles, earplugs, safety cap—before using this tool.
2. Be sure to use an air compressor authorized by the safety certification authority as a pressure source for operating this tool within the optimum range of pressure (58~100psi).
3. Make sure that this tool has no trouble about the safety device, the trigger, fasteners such as bolts, and so on.
4. Inject three or four drops of oil used exclusively for a nailer into the air plug before using this tool. (Do this regularly once a day if possible.)
5. Check the air line and the air connector for damage and don't use longer air line than necessary (over 5m).

Preliminary Checkup


1. To give a checkup to the tool, adjust the operating pressure to 70 psi (5 kgf/cm²) before air connection.
2. Keep pressure low as far as it may cause no trouble in operation Within the optimum range of pressure according to hardness of the working plane and length of nails.

1. Loading nails

⚠ WARNING

Turn the muzzle downward and never pull the trigger in loading or unloading nails.

- 1) Pull the magazine backward with the click lever pressed.
- 2) Load nails from the side of the magazine.
- 3) Keep pushing the magazine until it is fixed in the click lever.



2. Unloading nails

- 1) Pull the magazine backward with the click lever pressed.
- 2) Unload nails from the side of the magazine.
- 3) Keep pushing the magazine until it is fixed in the click lever.

4. Maintenance and Inspection

<Caution prior to inspection and maintenance>

* Be sure to read the safety instruction before inspecting or maintaining this tool.

⚠ WARNING

Be sure to disconnect the air line before clearing jam, or repairing or inspecting the tool.

1. Clearing a Jam

If jam occurs during the nailing process, clear it according to the following procedure.

- 1) Disconnect the air line from the tool.
- 2) Unload nails left in the magazine.
- 3) Open the guide cover B.
- 4) Use a long nose to remove a nail caught in.



⚠ CAUTION

- After clearing jam, make sure that the product has no trouble before using it.
- If jam or other factors damage main parts, it can prevent normal operation.
- If any trouble occurs, stop using the tool and ask a nearby A/S center or a distributor for A/S.

2. Inspecting the Magazine

- 1) Disconnect the air line from the tool.
- 2) Inspect if the inside of the magazine is cleared or damaged.
(Dust or alien substances such as pieces of wood in the operation body of the pusher within the magazine can prevent smooth operation.)

3. Storing

- 1) When not in use for an extended period, apply a thin coat of the lubricant to The steel parts to avoid rust.
- 2) Do not store the tool in a cold weather environment. Keep the tool in a warm area.
- 3) When not in use, the tool should be stored in a warm and dry place.
Keep out of reach of children.
- 4) All quality tools will eventually require servicing or replacement of parts because of wear from the normal use.

4. Maintenance Chart (Reference)

5. Operator Troubleshooting (Reference)



★ Supplement to the operating instruction

According to the European Norm EN 792-13 the regulation is valid from 01.01.2001 that all fastener driving tools with contact actuation must be marked with the symbol "Do not use on scaffoldings, ladders" and they shall not be used for specific application for example:

- * When changing one driving location to another involves the use of scaffoldings, stairs, ladders or ladder alike constructions e.g. roof laths,
- * closing boxes or crates,
- * fitting transportation safety systems e.g. on vehicles and wagons.

5. Service and Repairs (A/S Request)

WARNING

- It is important to note that users or distributors who want to have this tool repaired must get A/S from A/S personnel trained in JITOOL.
- Use only parts supplied or authorized by JITOOL for repair.

6. Maintenance Chart & Operator Troubleshooting

1) Maintenance Chart


Practice	Reason	Method
Drain air line filter daily	Prevent accumulation of moisture and dirt.	Open manual petcock.
Keep lubricator filled.	Keep the tool lubricated	Fill with JITOOL pneumatic tool lubricant.
Clean magazine and feeder mechanism.	Prevent a jam & Dry fire.	Blow clean daily.
Lubricate the Tool after nailing.	Extend the tool life.	Supply 3~4 drops of lubricant into the tool.
Drain air compressor.	Keep the tool operated properly.	Open petcock on air compressor tank.

2) Operator Troubleshooting

Problem	Check Method	Correction
Tool operates, but no nail is driven.	Check air pressure.	Reduce air pressure. (58~100psi)
	Check for a jam.	Clean a jam. (Refer to 4-1)
	Check for proper nail.	Use only recommended nails.
Tool does not operate.	Check air line & Plug	Check for air line connection and damage to fitting part (Change it in case of damage)
	Check for abnormality in head valve	Change O-ring in case of damage

Weak drive. Slow to cycle.	Check air pressure.	Reduce air pressure. (58~100psi)
	Check position Piston set.	Readjust.
	–	Supply of lubricant into the tool.
	Driver blade worn or damaged?	Part change (Contact JITOOL or Distributor)
	Piston O-ring worn or damaged?	
Nail driven too deep or shallow	Check air pressure.	Reduce air pressure. (58~100psi)
Skipping nails, Intermittent feed.	Check air pressure.	Reduce air pressure. (58~100psi)
	Check for proper nail.	Use only recommended nails.
	–	Supply of lubricant into the tool.
	Piston O-ring cut or heavily worn ?	Part change. (Contact JITOOL or Distributor)
Drives properly during normal operation, but does not drive fully at faster nailing speeds.	Check air pressure.	Reduce air pressure. (58~100psi)
	Check inside diameter of air hose.	Use larger air hose.

EXPLODED DIAGRAM OF 1850A




1850A (18GA. 50mm LONG. BRAD NAILER)

NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY
1	EXHAUST COVER	422-C-103	1	24	AIR PLUG	9032-B-005	1	48	GUIDE COVER B	1850A-G-003	1
2	BOLT (M5x25L)	Z-05-250	4	25	PLUG CAP	9032-B-006	1	49	BOLT (M4x16L)	ZN-04-160	2
3	CAP	1850A-C-001	1	26	GRIP	1850-B-104	1	50	DRIVER GUIDE	1850A-G-001	1
4	GASKET	1850A-C-102	1	27	VALVE SET	1850-V-P001	1	51	STEEL PLATE	F30-M-005	1
5	HEAD VALVE SEAL A	422-H-007	1	28	VALVE PLUNGER O-RING	CT64-V-004	1	52	PUSHER	1850A-M-103	1
6	CAP SPRING	422-H-006	1	29	VALVE PLUNGER	1850-V-007	1	53	PUSHER SPRING	1850-M-004	2
7	CAP O-RING	422-H-010	1	30	PLUNGER SPRING	1850-V-009	1	54	MAGAZINE A	1850A-M-001	1
8	HEAD VALVE O-RING	1850-H-004	1	31	PLUNGER O-RING	CT64-V-008	2	55	MAGAZINE B	1850A-M-002	1
9	HEAD VALVE	1850-H-201	1	32	PLUNGER	1850-V-010	1	56	BOLT (M4x8L)	Z-04-080	1
10	HEAD VALVE SEAL O-RING	1850-H-009	1	33	PLUNGER CAP O-RING	1013-V-011	1	57	SPRING WASHER (for M4)	W-04	1
11	HEAD VALVE SEAL B	422-H-008	1	34	PLUNGER CAP	1850-V-012	1	58	TWIN NUT	1850-M-012	2
12	COLLAR	1850-A-004	1	35	TRIGGER SPRING	1013-T-006	1	59	MAGAZINE END CAP	1850-L-101	1
13A	PISTON SET	1850-P-P101	1	36	PIN STOPPER O-RING	CT64-M-008	1	60	BUSHING	CT64-L-007	2
13	PISTON ASSEMBLY	1850-P-P102	1	37	TRIGGER A(OUT)	1850-T-001	1	61	BOLT (M4x12L)	ZN-04-120	2
14	PISTON O-RING	1850-P-003	1	38	PIN GUIDE	1850-T-003	1	62	CLICK LEVER	CT64-L-002	1
15	CYLINDER	1850-A-001	1	39	TRIGGER PIN	422-T-008	1	63	CLICK LEVER SPRING	CT64-L-004	1
16	CYLINDER O-RING	1850-A-005	2	40	TRIGGER B (IN)	1850-T-002	1	64	ROLL PIN (Φ3x18L)	R-30-180	1
17	CYLINDER GUIDE	1850A-A-002	1	41	ROLL PIN (Φ3x14L)	R-30-140	1	65	BRACKET	1850-M-106	1
18	CYLINDER GUIDE O-RING	1865-A-005	1	42	BOLT (M5x22L)	Z-05-220	2	66	BOLT (M5x12L)	Z-05-120	1
19	BUMPER	1850-A-003	1	43	GUIDE COVER A	1850A-G-102	1	68	BOLT (M4x6L)	ZN-04-060	2
20	NOZZLE	F30-B-007	1	44	CONTACT ARM	1850A-S-002	1	69	LOCK NUT (for M5)	NN-05	1
21	BODY	1850A-B-301	1	45	SAFETY LEVER	1850-S-111	1	70	PUSHER HOLDER	F30-M-013	2
22	END CAP O-RING	422-B-003	1	46	BOLT (M4x10L)	Z-04-100	2				
23	END CAP	422-B-002	1	47	SAFETY GUIDE COVER	1850A-S-010	1				

** All the parts of nailer can be changed for improvement and re-design without announcement.

(REV. : 2021/10/05)

EXPLODED DIAGRAM OF 1850N




1850N (18GA. 2" LONG. BRAD NAILER)

NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY	NO.	DESCRIPTION	PART NO.	QTY
1	EXHAUST COVER	422-C-103	1	24	AIR PLUG	9032-B-005	1	48	GUIDE COVER B	1850A-G-003	1
2	BOLT (M5x25L)	Z-05-250	4	25	PLUG CAP	9032-B-006	1	49	BOLT (M4x16L)	ZN-04-160	2
3	CAP	1850A-C-001	1	26	GRIP	1850A-B-104	1	50	DRIVER GUIDE	1850N-G-001	1
4	GASKET	1850A-C-102	1	27	VALVE SET	1850-V-P001	1	51	STEEL PLATE	F30-M-005	1
5	HEAD VALVE SEAL A	422-H-007	1	28	VALVE PLUNGER O-RING	CT64-V-004	1	52	PUSHER	1850A-M-103	1
6	CAP STRING	422-H-006	1	29	VALVE PLUNGER	1850-V-007	1	53	PUSHER SPRING	1850-M-004	2
7	CAP O-RING	422-H-010	1	30	PLUNGER SPRING	1850-V-009	1	54	MANAZINE A	1850N-M-001	1
8	HEAD VALVE O-RING	1850-H-004	1	31	PLUNGER O-RING	CT64-V-008	2	55	MANAZINE B	1850N-M-002	1
9	HEAD VALVE	1850-H-201	1	32	PLUNGER	1850-V-010	1	56	BOLT (M4x8L)	Z-04-080	1
10	HEAD VALVE SEAL O-RING	1850-H-009	1	33	PLUNGER CAP O-RING	1013-V-011	1	57	SPRING WASHER (for M4)	W-04	1
11	HEAD VALVE SEAL B	422-H-008	1	34	PLUNGER GAP	1850-V-012	1	58	TWIN NUT	1850-M-012	2
12	COLLAR	1850-A-004	1	35	TRIGGER SPRING	1013-T-006	1	59	MANAZINE END CAP	1850-L-101	1
13A	PISTON SET	1850-P-P101	1	36	PIN STOPPER O-RING	CT64-M-008	1	60	BUSHING	CT64-L-007	2
13	PISTON ASSEMBLY	1850-P-P102	1	37	TRIGGER A(OUT)	1850-T-001	1	61	BOLT (M4x12L)	ZN-04-120	2
14	PISTON O-RING	1850-P-003	1	38	PIN GUIDE	1850-T-003	1	62	CLICK LEVER	CT64-L-002	1
15	CYLINDER	1850-A-001	1	39	TRIGGER PIN	422-T-008	1	63	CLICK LEVER SPRING	CT64-L-004	1
16	CYLINDER O-RING	1850-A-005	2	40	TRIGGER B (IN)	1850-T-002	1	64	ROLL PIN (Φ3x18L)	R-30-180	1
17	CYLINDER GUIDE	1850-A-002	1	41	ROLL PIN (Φ3x14L)	R-30-140	1	65	BRACKET	1850-M-106	1
18	CYLINDER GUIDE O-RING	1665-A-005	1	42	BOLT (M5x22L)	Z-05-220	2	66	BOLT (M5x12L)	Z-05-120	1
19	BUMPER	1850-A-003	1	43	GUIDE COVER A	1850A-G-102	1	68	BOLT (M4x6L)	ZN-04-060	2
20	NOZZLE	F30-B-007	1	44	CONTACT ARM	1850A-S-002	1	69	LOCK NUT (for M5)	NN-05	1
21	BODY	1850A-B-301	1	45	SAFETY LEVER	1850-S-111	1	70	PUSHER HOLDER	F30-M-013	2
22	END CAP O-RING	422-B-003	1	46	BOLT (M4x10L)	Z-04-100	2				
23	END CAP	422-B-002	1	47	SAFETY GUIDE COVER	1850A-S-010	1				


** All the parts of nailer can be changed for improvement and re-design without announcement.

(REV.: 2021/10/05)

MEMO



MEMO



Better Tools, Better Works!

JITOOL 제일타카(주)

JITOOL KOREA

18, Jikdong-ro, Gwangju-si, Gyeonggi-do 464-090, Korea
Tel. +82-2-445-2500 Fax. +82-2-445-2506
E-mail. jitool@jitoool.com / www.jitoool.com

JITOOL USA CORP.

14408 Iseli Road, Santa Fe Springs,
CA 90670, USA
Tel. +1-562-404-8740 Fax. +1-562-404-8490