


# Model No.DMR050 FLASHLIGHT RADIO



**Model No.DMR050 FLASHLIGHT RADIO**

Bản vẽ	Mã Phụ tùng	Mô tả	Tương ứng với	Số lượng	Cũ/ Mới	Ghi chú 1	Ghi chú 2
001	SE00000108	LIGHT COVER		1			
002	SE00000109	LED MOUDLE		1			
C10	SE00000110	REFLECTOR		1			
003	SE00000111	LIGHT REAR COVER		1			
004	SE00000112	C RING		1			
005	SE00000113	SCREW M4X15		1			
006	SE00000114	WASHER 4		1			
007	SE00000115	SCREW M3X8		1			
008	SE00000116	STEEL BALL 4		2			
009	SE00000117	CLICK SPRING		2			
010	SE00000118	ROD ANT		1			
011	SE00000119	SCREW M2.6X7		1			
012	SE00000120	SCREW M3X10		5			
013	SE00000121	REAR CABINET		1			
014	SE00000119	SCREW M2.6X7		4			
015	SE00000122	SPEAKER KIT		1			
016	SE00000123	SPEAKER GRILL		1			
017	SE00000120	SCREW M3X10		4			
018	SE00000124	PUSH KNOB		1			
019	SE00000119	SCREW M2.6X7		3			
020	SE00000125	LIGHT KNOB ASSY		1			
021	SE00000126	PUSH KNOB		1			
022	SE00000127	WIRE COVER		1			
023	SE00000119	SCREW M2.6X7		1			
024	SE00000128	LIGHT SHAFT		1			
025	SE00000129	FRONT CABINET		1			
026	SE00000130	CIRCUIT BOARD C ASSY		1			
027	SE00000119	SCREW M2.6X7		7			
028	SE00000133	CIRCUIT BOARD A ASSY		1			
030	SE00000134	SENSOR TERMINAL ASSY		1			
031	SE00000135	SCREW M2X5		2			
032	SE00000136	BAR ANT ASSY		1			
033	SE00000137	PUSH KNOB FUNCTION		1			
A01	SE00000138	STRAP		1			