

Model No.MR010G CORDLESS RADIO WITH LANTERN

Bản vẽ	Mã Phụ tùng	Mô tả	Tương ứng với	Số lượng	Cũ/ Mới	Ghi chú 1	Ghi chú 2
001	SE00001125	TOP PANEL		1			
002	SE00001127	TAPPING SCREW 3X12(ZK)		6			
003	SE00001128	TOP COVER		1			
004	SE00001129	O RING D37.8 W2		1			
005	SE00001130	FLASH LIGHT LENS		1			
006	SE00001131	LED LENS		1			
008	SE00001127	TAPPING SCREW 3X12(ZK)		4			
009	SE00001133	LED HOLDER+PCB F ASS'Y		1			
009		INC. 10					
010	SE00001136	RUBBER PAD A		2			
011	SE00001137	HANDLE		1			
013	SE00001138	WATERPROOF PLUG A		1			
014	SE00001139	TOP CABINET ASS'Y		1			
015	SE00001140	HEX SOCKET HEAD BOLT M4X16		4			
016	SE00001141	FIXER BAR		1			
017	SE00001216	HEX SOCKET HEAD BOLT M4X13		1			
018	SE00001127	TAPPING SCREW 3X12(ZK)		4			
019	SE00001143	SPEAKER		1	*		
019-1	SE00001143	SPEAKER	O	1			
020	SE00001146	PACKING		1			
021	SE00001147	ANT WIRE		2			
022	SE00001148	SCREW STB 3X12(MC)		4			
023	SE00001149	WATERPROOF PLUG B		1			
024	SE00001150	LAMP COVER ASS'Y		1			
025	SE00001141	FIXER BAR		1			
026	SE00001216	HEX SOCKET HEAD BOLT M4X13		1			
027	SE00001141	FIXER BAR		1			
028	SE00001216	HEX SOCKET HEAD BOLT M4X13		1			
029	SE00001141	FIXER BAR		1			
030	SE00001216	HEX SOCKET HEAD BOLT M4X13		1			
031	SE00001218	HEX SOCKET HEAD BOLT 3X12		4			
032	SE00001221	PCB D+E ASSY		1			
033	SE00001127	TAPPING SCREW 3X12(ZK)		5			
034	SE00001222	REAR BOTTOM CABINET ASS'Y		1			
034		INC. 35					
035	SE00001158	USB RUBBER COVER		1			
036	SE00001159	PCB K ASS'Y		1			
037	SE00001160	TAPPING SCREW 2X6		2			
038	SE00001161	PCB H ASS'Y (USB JACK)		1			
039	SE00001160	TAPPING SCREW 2X6		4			
040	SE00001163	BOTTOM CABINET PACKING D1. 5xL2		1			
041	SE00001164	PCB P+TERMINAL ASSY		1			
042	SE00001160	TAPPING SCREW 2X6		4			
043	SE00001227	PCB A ASS'Y		1			
044	SE00001160	TAPPING SCREW 2X6		4			
045	SE00001229	PCB C ASS'Y(CE)		1			
047	SE00001235	FRONT BOTTOM CABINET ASS'Y		1			

A01	SE00001178	STRAP WITH HOOK		1			
-----	------------	-----------------	--	---	--	--	--