


Model No.SJ401 SCROLL SAW



Model No.SJ401 SCROLL SAW

Bản vẽ	Mã Phụ tùng	Mô tả	Tương ứng với	Số lượng	Cũ/ Mới	Ghi chú 1	Ghi chú 2
002	303209-000	HOSE		1			
003	303071-001	KNOB		1			
005	021200-001	SPRING WASHER		1			
006	021101-027	FLAT WASHER		1			
007	020613-001	HEX.SOCKET BOLT		1			
008	270310-000	BLADE SUPPORTER & GUARD		1			
009	021104-023	FLAT WASHER		1			
010	020601-003	HEX.SOCKET BOLT		1			
011	290081-000	DUST BLOWER		1			
012	021104-023	FLAT WASHER		1			
013	020601-003	HEX.SOCKET BOLT		1			
015	290079-000	SUPPORT ROD		1			
016	026104-001	PIN SPRINGR		1			
017	020601-003	HEX.SOCKET BOLT		1			
018	021104-023	FLAT WASHER		1			
019	270309-000	HOLD DOWN FOOT		1			
020	020505-003	SET SCREW		1			
021	225070-000	HOLD DOWN BLOCK		1			
022	303204-003	MOTOR REAR COVER		1			
C10	303205-001	BRUSH HOLDER		2	*		
023	050007-000	BEARING		1			
024	900312-000	FIELD ASS'Y WITH MOTOR HOUSING		1			
027	375009-001	CARBON BRUSH		2			
028	303000-001	BRUSH HOLDER CAP		2			
029	224053-000	TABLE		1			
030	021402-001	WAVE WASHER		1			
031	020614-001	SOCKET HEAD SCREW		1			
032	270311-000	TILT BRACKET		1			
033	021101-025	FLAT WASHER		1			
035	900403-000	LOCK HANDLE ASS'Y		1			
038	080171-000	POWER CORD		1			
039	020219-001	SCREW		3			
040	880084-000	ARMATURE ASS'Y WITH BEARING S		1			
040		INC. 23,41					
041	050015-100	BEARING		1			
042	225083-000	MOTOR FRONT COVER		1			
043	240051-000	BASE		1			
044	020103-015	SCREW		1			
045	913002-000	BUSHING		1			
046	913002-000	BUSHING		1			
047	020103-015	SCREW		1			
048	270248-000	BUSHING SET COVER		1			
049	302043-003	SWITCH CASE		1			
050	020103-015	SCREW		1			
053	863305-006	INDICATION LABEL		1			
054	022804-000	NUT		1			
055	290080-000	LOCK POST		1			

056	020228-001	SCREW		1		
057	303259-001	SWITCH COVER		1		
058	021308-001	EXT.TOOTH WASHER		1		
059	020103-015	SCREW		1		
060	022301-001	NUT		1		
061	020103-015	SCREW		1		
062	020103-015	SCREW		1		
063	020228-001	SCREW		1		
065	303207-000	CONTROL KNOB		1		
067	370021-000	SWITCH,WASHER & NUT		1		
068	020726-001	PAN HEAD SCREW		1		
069	270249-000	POINTER		1	*	
069-1	303242-000	POINTER	O	1		
071	021306-001	LOCK WASHER		1		
073	020103-015	SCREW		2		
074	021306-001	LOCK WASHER		1		
075	020720-003	SCREW & WASHER		2		
076	020720-003	SCREW & WASHER		2		
077	240042-000	COUNTERWEIGHT		1		
078	060047-000	SPACER		1		
079	020508-001	SET SCREW		1		
080	020723-007	SCREW & WASHER		3		
081	270308-000	PLATE COVER		1		
082	020106-013	SCREW		1		
083	024201-001	PULL NAIL		1		
084	024201-001	PULL NAIL		1		
085	303202-000	BLADE STORAGE CASE		1		
086	020106-013	SCREW		1		
087	020200-017	SCREW		2		
088	020200-017	SCREW		2		
089	900782-006	BOARD COVER ASSY (220V)		1		
090	900625-004	CONTROL BOARD ASS'Y (220V)		1		
091	225112-000	ARM COVER(LEFT)		1	*	
091-1	900570-000	ARM COVER SET	<	1		
092	026202-007	PIN		1		
093	020702-001	COVER SET SCREW		1		
094	020702-001	COVER SET SCREW		1		
095	020702-001	COVER SET SCREW		1		
096	020702-001	COVER SET SCREW		1		
097	020702-001	COVER SET SCREW		1		
098	225111-000	ARM COVER(RIGHT)		1	*	
099	330026-000	AIR DIAPHRAGM		1		
100	020702-001	COVER SET SCREW		1		
101	020702-001	COVER SET SCREW		1		
102	020702-001	COVER SET SCREW		1		
103	225069-000	BLADE TENSION LEVER		1		
104	026104-009	PIN		1		
105	290078-000	TENSION ADJUSTING BOLT		1		
106	021100-011	FLAT WASHER		1		
108	029141-001	SPRING		1		
109	026103-015	ROLL PIN		1		

110	020608-003	HEX.SOCKET BOLT		1		
111	250006-000	UPPER BLADE NUT		1		
112	029144-001	COMPRESSION SPRING		1		
113	250005-000	UPPER BLADE HOLDER		1		
114	250004-000	LOWER BLADE NUT		1		
115	026103-015	ROLL PIN		1		
116	029144-001	COMPRESSION SPRING		1		
117	250003-000	LOWER BLADE HOLDER		1		
118	026107-001	PIN		1		
119	020608-003	HEX.SOCKET BOLT		1		
120	026107-001	PIN		1		
121	225073-000	BLADE SUPPORT		1		
122	026102-007	PIN		1		
123	020600-001	HEX. SOCKET BOLT		1		
124	026103-015	ROLL PIN		1		
125	060052-000	SPACER		1		
126	303201-000	ARM LINK		1		
127	050012-000	BEARING		1		
128	270252-000	BEARING FENCE		1		
129	020200-015	SCREW		1		
130	022101-001	NUT		1		
131	021101-027	FLAT WASHER		1		
132	050012-000	BEARING		1		
133	224042-000	LOWER ARM		1		
134	053014-000	BEARING FLANGE		1		
135	028935-001	SET SCREW		1		
136	021202-003	SPRING WASHER		1		
137	022101-001	NUT		1		
138	290077-000	ARM PIN		1		
139	053014-000	BEARING FLANGE		1		
140	053014-000	BEARING FLANGE		1		
141	270251-000	CONNECTOR		1		
142	028935-001	SET SCREW		1		
143	021202-003	SPRING WASHER		1		
144	022101-001	NUT		1		
145	224041-000	UPPER ARM		1		
146	290077-000	ARM PIN		1		
147	053014-000	BEARING FLANGE		1		
148	914019-000	SPONGE		1		
149	020127-003	SCREW		2		
150	090042-000	SWITCH		1		
151	020216-005	SCREW		2		
152	990026-000	MOTOR		1		
152		INC. 22-24,27,28,40-42,149			*	
152		INC. 22-24,27,28,40-42,149,153				
153	303205-001	BRUSH HOLDER		2		
154	021410-001	WASHER		1		
A02	040026-001	BLADE CHANGING ROD		1		
A03	040005-003	HEX WRENCH "L" M3		1		
A04	040006-001	HEX WRENCH "L" M4		1		