




EN	Cordless Pole Saw	INSTRUCTION MANUAL	10
ZHCN	充电式高枝锯	使用说明书	24
ID	Gergaji Galah Tanpa Kabel	PETUNJUK PENGGUNAAN	39
MS	Gergaji Tiang Tanpa Kord	MANUAL ARAHAN	55
VI	Máy Cưa Cành Trên Cao Cầm Tay Hoạt Động Bằng Pin	TÀI LIỆU HƯỚNG DẪN	70
TH	เลื่อยตัดแต่งกิ่งไม้สูงไร้สาย	คู่มือการใช้งาน	84

DUA200



























Fig.1










Fig.23




Fig.24




Fig.25




Fig.26




Fig.27



















Fig.28








Fig.44




Fig.45




Fig.46




Fig.47




Fig.48




Fig.49




Fig.50

