











EN	Cordless Circular Saw	INSTRUCTION MANUAL	8
ZHCN	充电式电圆锯	使用说明书	22
ID	Gergaji Bundar Nirkabel	PETUNJUK PENGGUNAAN	37
MS	Gergaji Bulat Tanpa Kord	MANUAL ARAHAN	53
VI	Máy Cưa Đĩa Cầm Tay Hoạt Động Bằng Pin	TÀI LIỆU HƯỚNG DẪN	68
TH	เลื่อยวงกลมไร้สาย	คู่มือการใช้งาน	82

HS013G








Fig.7




Fig.8




Fig.9




Fig.10




Fig.11




Fig.12




Fig.13




Fig.14




Fig.15




Fig.16




Fig.17

