


## EXPLODED DIAGRAM : FS-100C

### WARNING

This diagram is for your reference only. Do not attempt to service or repair the Tool. Do not take the Tool apart. Contact an authorized Nitto dealer for all service and repair of the Tool. Improper service and repair can cause accidents and service injuries. Never attempt to modify the Tool. Never attempt service or repair the Tool yourself.

Exploded diagram/parts list are subject to change at any time without notice. (As of May. 2013)



The part numbers with ( ) are included in the Ass'y parts written above them.

No.	Part No.	Description	Qty	Price
29	TB08683	Housing Cover Ass'y	1set	
1	(TP15371)	Housing Cover	1	
27	(TP04218)	Label NITTO	1	
28	(TQ12752)	Warning Label CE Mark	1	
2	TP15374	Trigger	1	
3	TA99365	Housing Sub Ass'y	1set	
4	TP04234	Spring Lock Washer M4	4	
5	TPI 4488	Cross Recessed Pan Head Tapping screw 4 x 20	4	
6	TP15376	Spring 0.45 x 3.1 x 17	1	
7	TPI 5375	Cancel Switch	1	
8	TA91647	Tube Ass'y	1set	
26	TA99971	CLamp Ass'y	2set	
9	(TP10870)	Clamp Spring	2	
10	(TP11245)	Cross Recessed Pan Head Screw 4x10	8	
11	(TP10872)	Clamp Stopper B	2	
12	(TP17901)	Clamp Stopper C	4	
13	(TP10871)	Clamp Stopper A	2	
14	TA9A372	Base Plate Sub Ass'y	1set	
16	TA99364	Throttle Valve Ass'y	1set	

No.	Part No.	Description	Qty	Price
17	TA91575	Cross Recessed Pan Head Screw 4 x 8 Ass'y	1set	
19	TP16951	Filter	1	
20	TA96330	Rubber Support Ass'y	4set	
21	TA9A369	Turbine Ass'y	1set	
22	TP03790	O Ring S-56	1	
23	TA9A371	End Cap Ass'y	1set	
24	TP01945	Hex. Socket Head Cap Screw 5 x 12	1	
25	TA9A367	Rubber Pad Ass'y	1set	

#### ACCESSORIES

No.	Part No.	Description	Qty	Price
15	TB08077	Air Hose H Ass'y	1set	
	TP02236	Bushing R 1/4 x NPT 1/4	1	
		Abrasive paper # 180	5	
		Abrasive paper # 240	5	
	TQ12753	Instruction Manual	1	
	TQ12754	Declaration of Conformity	1	