


EXPLODED DIAGRAM : FS-50A

WARNING

This diagram is for your reference only. Do not attempt to service or repair the Tool. Do not take the Tool apart. Contact an authorized Nitto dealer for all service and repair of the Tool. Improper service and repair can cause accidents and service injuries. Never attempt to modify the Tool. Never attempt service or repair the Tool yourself.

Exploded diagram/parts list are subject to change at any time without notice. (As of May. 2013)



www.npower.com.vn

Tài liệu được tổng hợp bởi đội ngũ kỹ thuật của **NPOWER**
Bản quyền nội dung thuộc về **NITTO KOHKI**

Powered by **NAVITECH** | www.navitech.co

The part numbers with () are included in the Ass'y parts written above them.

No.	Part No.	Description	Qty	Price
25	TB08684	Housing Sub Ass'y	1set	
1	(TP05700)	Housing	1	
22	(TP04218)	Label NITTO	1	
23	(TQ12752)	Warning Label CE Mark	1	
24	(TP05745)	Name Plate	1	
2	TP05698	Valve Nipple	1	
3	TA97589	Trigger Ass'y	1set	
4	(TP1200)	ORingP - 10	2	
5	TA91647	Tube Ass'y	1set	
6	TP05708	Clamp Stopper	2	
7	TP05707	Clamp Spring	2	
8	TQ1 725	Hex. Socket Countersunk Head Screw 3 x 6	4	
9	TP04226	Cross Recessed Countersunk Flat Head Screw 6 x 14	1	
10	TA99828	Rubber Pad Ass'y	1set	
11	TA91575	Cross Recessed Pan Head Screw 4x8 Ass'y	4sets	
12	TP05701	Housing Cap	1	
13	TP04217	Cross Recessed Raised Countersunk Head Screw 4 x 10	2	

No.	Part No.	Description	Qty	Price
14	TA91 465	Rubber Support Ass'y	4sets	
15	TP05705	End Plate	1	
16	TP0571 2	Cross Recessed Countersunk Flat Head Screw 4 x 6	4	
17	TP05706	Steel Ball (15/32")	1	
18	TA92337	Cylinder Sub Ass'y	1set	
19	(TP05703)	Cylinder	1	
20	TP06290	Cross Recessed Pan Head Screw with Spring Lock Washer 4 x 8	4	

ACCESSORIES

No.	Part No.	Description	Qty	Price
21	TB08077	Air Hose H Ass'y	1set	
	TP02236	Bushing R 1/4 x NPT 1/4	1	
		Abrasive paper # 180	5	
		Abrasive paper # 240	5	
	TQ12753	Instruction Manual	1	
	TQ12754	Declaration of Conformity	1	