

Exploded View/Parts List

MYG-70 Exploded View/Parts List


⚠ CAUTION

- Users should never perform disassembly of the tool.

This illustration is for reference only.

For repair or replacement of the tool, request service from the retailer where you purchased the tool or the nearest NITTO service member store.

Exploded view/parts list are subject to change at any time without notice. (As of Apr. 2018)



*1 indicates a consumable item, *2 indicates a commercial item. Parts inside () are components of the above assembly.

No.	Part no.	Part name	Quantity
*1 *2	1	TQ12088 Needle Bearing BK1012	1
	2	TQ15021 Spindle	1
	3	TP09933 Parallel Key 4×4×12 Both Ends Round	1
	4	TQ14906 Parallel Key 4×4×13.3 One End Round	1
	5	TQ15022 Stop Ring I-0.9×18.5×8.6	1
*1	6	TQ12547 Gear	1
*1 *2	7	TP04138 Ball Bearing 6204ZZ	1
	8	TB08263 Bearing Set Screw Ass'y	1 set
	11	TQ15023 Driving Flange	1

Exploded view/parts list are subject to change at any time without notice. (As of Apr. 2018)

No.	Part no.	Part name	Quantity
*1 *2	12	TQ15258	Outer Flange 7/8
	13	TP11688	Outer Flange Bolt 12×25
	14	TP06242	Ball Bearing 629ZZ
	15	TQ12063	End Plate A
	16	TP04061	Spring Pin 3×6 AW
*1	17	TQ12062	Cylinder
	18	TQ14928	Rotor
	19	TB08555	Blade Ass'y (4 pcs.)
	20	TP10130	Parallel Key Both Ends Round 3×3×10
	21	TQ12064	End Plate B
*1 *2	22	TQ12087	Ball Bearing 638ZZ
*1	23	TQ12070	Pinion
	24	TB10399	Housing Sub Ass'y
	(25)	(TQ14942)	Label Model
	(26)	(TQ15216)	Label Warning
*1	28	TQ14980	Plug 70
	29	TQ14946	+ Countersunk Head Screw 4×14
	30	TQ15090	Exhaust Cover 70
	31	TQ15140	Spacer
	32	TQ15143	Exhaust Filter 70
	33	TQ15142	Exhaust Plate 70
	34	TQ15141	Packing Cover 70
	35	TQ14863	Lock Pin
	36	TQ14865	Pin Guide
	37	TQ14864	Spring 0.6×6.9×8
	38	TQ14866	Lock Button
	39	TB10092	Governor Ass'y
	(40)	(TQ12813)	Base
	(41)	(TP01566)	Steel Ball Ø6
	(42)	(TQ12067)	Sleeve
	(43)	(TQ12090)	Needle Roller 2.5×13.8
	(44)	(TQ12069)	Spring 1.4×15.5×14.2
	(45)	(TQ12068)	Stopper
	46	TB10397	Valve Holder Ass'y
	(47)	(TQ15276)	Label Specification
	48	TP17452	Lock Ring
	49	TP17445	O-ring S-35.5
	50	TQ12662	Valve Body
	51	TB08669	Lever Ass'y
	(52)	(TP13893)	Spring Pin 3×22 AW
	53	TB09001	Valve Stem Ass'y
	54	TP10714	O-ring S-22
	55	TQ12668	Adjust Valve
	56	TP10448	Internal Retaining Ring C-24
	57	TP01658	Filter
	58	CP25821	O-ring JASO-1020
	59	TQ12671	Bushing M23×Rc 3/8

Accessories

No.	Part no.	Part name	Quantity
9	TB10371	Wheel Guard Ass'y	1 set
(10)	(TQ15256)	Label Warning Wheel Guard	1
27	TB08265	Handle Ass'y	1 set
	TQ02350	Bushing R 3/8 × NPT 3/8	1
	TP00170	6 mm Hex. Socket Screw Key	1
	TP11723	10 mm Hex. Socket Screw Key	1
	TQ15277	Instruction Manual	1