

Exploded View/Parts List


MYS-20L Exploded View/Parts List

⚠ CAUTION

- Users should never perform disassembly of the tool.

This illustration is for reference only.

For repair or replacement of the tool, request service from the retailer where you purchased the tool or the nearest NITTO service member store.



*1 indicates a consumable item, *2 indicates a commercial item. Parts inside () are components of the above assembly.

	No.	Part no.	Part name	Quantity
*1 *2	1	TQ12638	Needle Bearing BK0609T2	1
*1	2	TQ12986	Gear 1×22	1
*1 *2	3	TP00498	Ball Bearing 6001ZZ	1
	4	TB08597	Bearing Set Screw Ass'y	1 set

No.	Part no.	Part name	Quantity
*1 *2	5	TB09777 Spindle Sub Ass'y	1 set
	(6)	(TP10742) Chuck Nut	1
	7	TP10110 Cap	1
	8	TP03933 Ball Bearing 606ZZ	1
	9	TP10109 End Plate A	1
*1	10	TP00496 Spring Pin 2.5×6 AW	1
	11	TQ16397 Cylinder	1
	12	TP14224 Rotor	1
	13	TB11384 Blade Ass'y (4 pcs.)	1 set
	14	TP06322 Spacer 8×11×3	1
*1 *2	15	TQ12622 End Plate B	1
	16	TP00468 Ball Bearing 608ZZ	1
	17	TQ12985 Pinion 1×15	1
	18	TB11403 Housing Ass'y	1 set
	(19)	(TQ15260) Label Warning	1
*1	20	TQ15004 Plug 20	1
	21	TQ14950 + Countersunk Head Screw 4×16	1
	22	TQ14889 Exhaust Cover	1
	23	TQ16653 Muffler PVA	1
	24	TQ14949 Spacer	1
*1	25	TQ14891 Packing Cover	1
	26	TQ16118 Muffler 25	1
	27	TP10098 Lock Nut	1
	28	TP03468 Lock Ring	1
	29	TB11402 Valve Body Sub Ass'y	1 set
	(30)	(TQ16386) Label Specification	1
	31	TA93070 Valve Stem Ass'y	1 set
	32	TP06325 Adjust Valve	1
	33	TP11997 O-Ring KS-7	1
	34	TP06326 Spacer 6×12×1.2	1
	35	TP03695 Internal Retaining Ring C-12	1
	36	TB01152 Lever Ass'y	1
	(37)	(TP00460) Spring Pin 3×22 AW	1
	(38)	(TP05498) Spring Pin 2×16 AW	1
	39	TQ13625 Filter	1
	40	TQ16519 Spring for Filter	1

Accessories

No.	Part no.	Part name	Quantity
	TQ14382	PAD 2"	1
	TQ14383	PAD 1-1/2"	1
	TQ14384	PAD 1"	1
	TQ14358	Abrasive Disc 1" × #60	2
	TQ14359	Abrasive Disc 1" × #80	2
	TQ14360	Abrasive Disc 1" × #100	2
	TQ14361	Abrasive Disc 1" × #120	2
	TQ14366	Abrasive Disc 1-1/2" × #60	2
	TQ14367	Abrasive Disc 1-1/2" × #80	2
	TQ14368	Abrasive Disc 1-1/2" × #100	2
	TQ14369	Abrasive Disc 1-1/2" × #120	2
	TQ14374	Abrasive Disc 2" × #60	2
	TQ14375	Abrasive Disc 2" × #80	2
	TQ14376	Abrasive Disc 2" × #100	2
	TQ14377	Abrasive Disc 2" × #120	2
	TP02236	Bushing R 1/4 × NPT 1/4	1
	TP00475	Spanner 14	2
	TQ16387	Instruction Manual	1